


CHOOSE THE RIGHT POWER ADAPTOR FOR YOUR LAPTOP:







- 1 Identify your laptop model on the following pages to determine the Targus power products compatible with your machine.
- 2 Determine where you want to use your power supply (At Home or in the Car or Plane).
- 3 If you are still unsure simply freecall Targus for expert advice on the best product for your needs.



NEED FURTHER HELP CHOOSING THE RIGHT POWER ADAPTOR & TIP FOR YOUR LAPTOP?

Our customer service team are now available late night Monday to Friday as well as all day Saturday & Sunday to assist.

Simply Freecall **Australia** 1800 641 645
or **New Zealand** 0800 633 222

Power Adaptors	Universal*		Replacement AC	
Product Name	Universal 90 Watt Wall Power Adaptor	Universal 90 Watt Wall, Auto/Air Power Adaptor	Home/Office 75 Watt AC Laptop Power Adaptor	Home/Office 90 Watt AC Laptop Power Adaptor
Product Code	APA68AU	APM68AU	APA02AU	APA03AU
Voltage Output:	Universal* Output voltage set by tip	Universal* Output voltage set by tip	15 - 16 V	18.5 - 20 V
Ideal for	Home	Home, Car & Plane	Home	Home
Power Input	 AC wall	 AC wall  DC auto  DC air	 AC wall	 AC wall
Tips Included in Pack	L104, L105, L106, L107, L108, L109, L110, L111, L112	L104, L105, L106, L107, L108, L109, L110, L111, L112	M, N, P	N,P, R, S, T, U

* Please check the Targus website (www.targus.com.au) or call Targus on the numbers below for full compatibility on Universal Power Adaptors - alternatively check this chart.

Revised for products effective July 2010

If your laptop model is not listed on this chart or on the chart supplied with the product, please contact Targus on the numbers below.

WARNING: Damage can be caused by the use of incorrect power tips. Care must be taken to ensure the correct tip is selected for your computer (laptop or device) as Targus Australia Pty Limited will not accept responsibility for any consequential damage upon the use of the incorrect power tip. It is stressed damage can be caused by the use of incorrect power tips. Compatibility is determined by Targus and in no way suggests endorsement by laptop manufacturers. Warranty details for Targus power adaptors are outlined on the product packaging. Targus is a trademark of Targus and all other marks shown are the property of their respective owners.



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APA68AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - APAB39U			

Manufacturer	Model Name	Series	Tip	Tip	Tip	
Acer	AcerNote	367D, 367T, 390	L106	✗	P	
		350, 355, 356, 370C, 374, 850C	L106	✗	U	
	AcerNote Light	380, 350, 360, 370, 370C, 370P, 370PC, 372, 373, 373+, P100	L106	✗	U	
	Anywhere	1100LX, 1120LX	L106	✗	P	
			3023, 3025, 3025WLMi, 3053WXMi, 3102NWLMI, 3104LMI, 3683WXM, 4220-200508, 4520-301G12, 4520-5A0508, 5023WLMi, 5043WLMi, 5044WLMi, 5100-3372, 5112WLMi, 5315, 5520G-301G12, 5520G-402G16, 5520G-502G16, 5570z, 5580-6432, 5600, 5601AWLMI, 5610 Series, 5610-2273, 5610-4537, 5610-4610, 5610-4648, 5612WLMi, 5633WLMi, 5672WLMi, 5710 Series, 7520G-0602G20, 9300WLMi, 9305WSMi, 9425WSMi, 9500, AS3054WXM, AS4315, AS4920, AS5102AWLMI, AS5103WLMi, AS5104WLMi, AS5105WLMi, AS5520, AS5702, AS5720, AS5920, AS9305WLMi	L107	✗	✗
			1362WLMi, 1363WLCi, 1522WLMi, 1524WLMi, 5670	L106	✗	✗
	Aspire		1641WLMi, 1642, 1642WLMi, 1642XWLMi, 1683WLMi, 1691WLCi, 2012WLCi, 2012WLMi, 2025WLMi, 2920, 2930, 3002LC, 3002LMI, 3002WLC, 3003WLCi, 3003WLMi, 3004WLCi, 3005WLCi, 3022WLMi, 3050-1594, 3100-1405, 3100-1458, 3508, 3613, 3614WLMi, 3618AWLMI, 3620, 3622WXCi, 3623, 3623NWXMi, 3623WLCi, 3623WLMi, 3623WXCi, 3623WXM, 3624, 3624WXCi, 3624WXM, 3634LMI, 3634WLMi, 3680-2022, 3690-2710, 3693WLMi, 3993WLMi, 4330, 4315-2004, 4315-2904, 4520-5582, 4715-4053, 4935, 5002WLMi, 5003WLMi, 5024, 5050-4570, 5050-5430, 5050-5954, 5100, 5100-3357, 5100-3577, 5100-3583, 5100-3825, 5100-3949, 5100-3959, 5100-5033, 5100-5328, 5100-5840, 5100-5873, 5101AWLMI, 5101WLMi, 5102AWLMI, 5102WLMi, 5104WLMi, 5105WLMi, 5315-2142, 5315-2808, 5512FWLMi, 5512WLMi, 5513EWLM, 5514WLMi, 5514WXM, 5520-5281, 5520-5908, 5570-2067, 5570-2609, 5570-2758, 5570-2792, 5570-2935, 5570-4421, 5670WLMi, 5715, 5720-4230, 5720-4258, 5720-6113, 5735, 5735Z, 5920-6444, 5920-6574, 5920-6706, 6920-6141, 6920-6508, 6920-6621, 6920-6886, 6920G-583G25Bn, 6920G-583G32Bn, 6920G-6A3G25Bn, 6920G-6A4G25Mn, 6920G-814G32Bn, 6920G-834G32Bn, 6920G-934G32Bn, 6930-6809, 6930G-583G25Bn, 6930G-583G25Mn, 6930G-733G25Mn, 6935G-734G32Bn, 6935G-844G32Bn, 6935G-944G32Bn, 7520-5185, 7520-6A1G08Mi, 7520-7A1G08Mi, 7720-3A2G12Mi, 7720-5A2G16Mi, 7720-6381, 7720-6604, 7720-6844, 7720-6A2G25Mi, 7720G-302G25Mi, 7720G-302G25Mn, 7720G-302G32Hi, 7720G-5A2G16Mi, 7720Z-1A2G16Mi, 8920-6048, 8920G-6A3G25Bn, 8920G-6A4G32Bn, 8920G-834G32Bn, 8920G-934G50Bn, 8920G-934G64Bn, 8930G, 8930G-584G32Bn, 8930G-734G32Bn, 8930G-844G32Bn, 8930G-864G32Bn, 8930G-864G64Bn, 8930G-944G64Bn, AS3810T-354G25N, AS3935-754G25MN, AS4810T-354G32Mn, AS4810TG-944G50MN, AS5536-644G32Mn, AS5536G-644G32MN, AS5735-733G32MN, AS5738G-644G32MN, AS5738G-644G50MN, AS5738G-654G32MN, AS5810TG-354G50MN	L108	✗	✗
			Aspire One Netbook	751H, AOA110, AOA150, AOD150, AOD250, One, ZG5	L108	✗
	Extensa		2900	L107	✗	✗
			515	L105	P	✗
			366D, 368D, 900, Ess3-391T	L106	✗	P
			355, 500, 501DX, 501T, 502D, 503DX, 505DX, 506DX, 600, 610CD, 610CDT	L106	✗	U
	Ferrari		2300, 3000, 4220-5963, 5220, 5220-2385, 5220-301G12Mi, 5230-571G16Mn, 5620-2A2G12Mi, 5620Z-4A1G12Mi, 5630-582G16Mn, 5630Z-322G16Mn, X4220-2555, EX4420-5239, EX4420-5963, EX4620-4431, EX4620-4648, EX4620-6194, EX5420-5038, EX5620-4020, EX5620-4025, EX5620-4801, EX5620-6266, EX5620-6419	L108	✗	✗
			4005WLMi	L106	✗	✗
			3000LMI, 3400LMI, 4005LMI, 4006LMI, 4006WLMi	L106	✗	P
	Tablet		1100-604G25Mn, 1100-704G25Mi, 1100-804G32Mn, 5005WLMi-FR	L108	✗	✗
			TMC104TCI, TMC110TCi, TMC110Ti	L108	✗	✗
	TravelMate		2413, 2434WLMi, 2600, 3280, 3290, 4200 Series, 4200-4091, 4200-4320, 4200-4493, 4200-4854, 4220, 4270, 4672WLMi, 5610, 5620, 5710 Series, 6410, 6410-6189, 6410-6248, 6460, 6460-6263, 6460-6752, 6492, 6592, 7720, 8200 Series, 8204WLMi, 8210, 8216WLHi	L107	✗	✗
512DX, 512T			L105	P	✗	



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - APA68AU 90W AC/DC - APA69AU	75W AC APA02AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
Acer	TravelMate	4202WLMi	L106	✗	✗
		505DX, 506T, 507DX, 507T, 524TX, 524TXV	L106	✗	U
		230, 2300, 2301WLCi, 2303WLCi, 2304WLCi, 230x, 230xc, 230xv, 230xv-PRO, 2310 Series, 2350 Series, 2400, 2410, 2413WLMi, 2418AWLMi, 2450, 2451WLCi, 2480, 2480-2153, 2480-2551, 2480-2705, 2480-2779, 290, 291, 3000 Series, 3002WTMI, 3004WTMI, 3010 Series, 3200 Series, 3210, 3220, 3230, 3270-6637, 380, 4000WLCi, 4001WLCi, 4001WLMi, 4002WLMi, 4050 Series, 4060, 4061, 4062, 4062WLMi, 4064, 4070, 4072, 4072WLCi, 4072WLMi, 4074, 4080, 4100, 4101WLMi, 4150 Series, 4222WLMi, 4270-6206, 4501WLMi, 4600 Series, 4603WLMi, 4604WLMi, 4720-6218, 4720-6220, 5004WLMi, 5270-6565, 5320-301G08Mi, 5320-301G12Mi, 5330-571G16Mi, 5530G-703G25Mn, 5602WLMi, 5720-2A3G16Mi, 5720-4A1G16Mi, 5720-4A2G16Mi, 5720-4A3G16Mi, 5720-5678, 5720-6337, 5720-6462, 5720-6722, 5730-6B2G16Mn, 5730-6B2G25Mn, 5730-6B4G25Mn, 5730-844G32Mn, 5730-944G32Mn, 5730G-843G25Mn, 5730G-844G32Bn, 6000, 6292-5B2G16Mi, 6292-603G32Mi, 6292-834G25Mi, 6292-834G32Mi, 6293-5B3G32Mn, 6293-6B2G25Mn, 6293-842G25Mn, 6492-812G25Mn, 6493-844G32Mn, 6592G-602G25Mn, 6592G-834G25Mn, 6593-842G25Mn, 6593G-842G25Mn, 6593G-944G32Mn, 7520-7A1G12Mi, 7530, 7530-602G25Mn, 7720G-602G25Mi, 7720G-702G50Mi, 7730-6B3G25Mn, 7730-843G25Mn, 7730G-944G32Mn, 8000, 8100 Series, 8100A, 8103WLMi, 8104, 8104WLMi, 8105, C110, C110CTI, C110TI, C300, TM220, TM230, TM260, TM270, TM279, TM280, TM350, TM360, TM370, TM380, TM520, TM530, TM610, TM620, TM630, TM660, TM730, TM740, TM800, TMC110, TMC113LCI	L108	✗	✗
		4000	L108	✗	U
Asus		A1 Series, F7 Series, M1 Series, M5, M8 Series, S1 Series, S200, S200N	L107	✗	✗
		F7000, L1 Series, L7 Series, L8 Series, M5200N, M5N, S300N, S5, S5200N, S5N, S8 Series, T9 Series	L107	✗	T
		A2L, A3 Series, A3000, A3000N, A3500N, A3Ac, A3F, A3Fc, A3Fp, A3H, A3Hf, A3N/L, A3Vc, A3Vm, A3Vp, A6 Series, A6F, A6G, A6K, A6Kt, A6L, A6M, A6Ne, A6R, A6Rp, A6T, A6Tc, A6U, A6V, A6Va, A6Vm, A7c, A7D, A7J, A7Jc, A7K, A7S, A7Sv, A7V, A8F, A8H, A8Ja, A8Jm, A8Jp, A8Js, A8M, A8SC-A1, A8SC-B1, A8SC-B2, A8SC-X3, A9Rp, AK6, B1 Series, B50A-A1, B50A-B1, B50A-B2, B50A-C2, F2F, F2Hf, F2J, F2Je, F3E-A1, F3E-B1, F3E-B2, F3E-B3, F3Jc, F3Jm, F3Jp, F3Ka, F3KA-X4, F3Sa, F3SC-A1, F3SC-B1, F3SV-A1, F3SV-B1, F3SV-B2, F3SV-B3, F3SV-B4, F3SV-C1, F50Gx, F5N, F5V-A1, F5VL-A2, F5VL-B1, F5VL-D1, F6A-A2, F6V-A1, F7KR, F80S-A1, F8P-B1W, F8P-C1B, F8P-C1W, F8P-X2B, F8Sn-A1, F8Sn-B1, F8Sn-C1, F8Sn-D1, F8Sp-X1, F8SV-A1, F8Va-B1, F8Va-C1, F9Dc-A1, F9Dc-B1, F9E-A1, F9S, F9Sg-A1, G1S-A1, G1S-B1, G1S-B2, G1Sn-A1, G1Sn-B1, G1S-X1, G1S-X3, G2K, G2K-A1, G2S, G2S-A1, G2S-A4, G2S-B1, G2S-B2, G2S-X3, L2B, L2E, L3000C, L3000TP, L3C, L3D, L4000E, L4000H, L4000L, L4000R, L4500R, L4E, L4H, L4R, L50Vn-A1, L50Vn-B1, L50Vn-C1, M2 Series, M2000C, M2400N, M2C, M2E, M2N, M2Ne Series, M3000N, M3N, M3Np, M50Sa-AK023C, M50Sa-X1, M50Sv-A1, M50Sv-B1, M50Vm-A1, M50Vm-B1, M50Vm-B2, M50Vm-B4, M51A-A1, M51A-B1, M51E-A1, M51E-B1, M51Sn-A1, M51Sn-B1, M51Sn-C1, M51Sn-X2, M51Sr, M51Vr, M5A Series, M5Ae, M6, M6A, M6C, M6Ce, M6N, M6Ne, M6Rf, M70SA-A1, M70SA-B1, M70SA-X2, M70Vm-A1, M70Vm-B1, M70Vm-C1, M70Vn-C1, M70Vn-C2, M7V, M7VP, M9J, M9V, N20A-A1, N50VC, N50Vn-A1B, N50Vn-B1B, N50Vn-C1S, N50Vn-C2S, N50Vn-C3S, N50VN-FP154C, N51Vf, N51Vg, N80Vn-A1, N80Vn-B1, PRO50, PRO50N, PRO55, R1E-B1, R1E-D1, R1F, R1F-A1, R1F-A2, S1000N, S1N, S5A, S6F Leather Collection, S6FM, U1E, U1F, U2E-A1B, U2E-B1B, U2E-B3B, U2E-X3, U3S-A1B, U3S-A1W, U5A, U6E, U6E-A1, U6E-X2, U6E-X3, U6S, U6V, V1S, V1S-A1, V1S-B1, V1V-A1, V2S, V2S-A1, V2S-B1, V6 Series, V6J, W1 Series, W1000Na, W1J00VC, W1Jc Carbon, W2Jc, W2P, W3 Series, W3A, W3J, W3N, W3V, W3Z, W5A, W5Ae, W5F, W6A, W6F, W6Fp, W7J, W7S-A1B, W7S-A1W, W7S-B1B, W7S-B2B, W7S-B2W, W7S-B3B, W7S-B3W, X59SR-A1, X71SL-A1, X71SL-B2, Z61Ae, Z71A, Z71V, Z71Vp, Z91N/L, Z93E	L106	✗	✗
	Asus Netbook	N10J-A1, N10J-A2, N10Jc-A1	L106	✗	✗
	Grandio	F7400, L7000, L7000C, L7200, L7300	L107	✗	T
	Lamborghini	VX1, VX2S-A1B, VX2S-A1Y, VX2S-A2B, VX2S-A2Y, VX2S-B1B, VX2S-B1Y, VX2S-B2B, VX2S-B2Y, VX3-A1B, VX3-A1Y	L106	✗	✗



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APAB8AU	90W AC/DC - APAB9AU	75W AC APAO2AU	90W AC APAO3AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
BenQ	Joybook	527, 5000, 5100, 5120, 6000, 7000, 5100N, 5100U, A82, DH7000, R53, S52, S52E, S53, S53W, S72 Series	L107	✗	✗
		2100, 8000, 8100, A2400H, A32, A32E	L106	✗	P
		2100, 2100e, 3000, 3000v1, DH5000, DH5100, S100, V11, V12, V33, V37	L108	✗	T
Compaq	Armada	110, E500, E500S, E700, M300, M700, V300	L107	✗	T
	Business Tablet	TC4400	L111	✗	✗
	Evo	N110, N150, N200, N400c, N410c, N600c, N610c, N620c, N800c, N800v, N800w, N1000v, N1015v, N1020c, N1020v	L107	✗	T
		N115, N160, N180	L106	✗	P
	Mini NetBook	102	L125 ☎ Freecall now for free tip!	✗	✗
	Presario	2203AP, 2204AP, 2205AP, 2206AP, 2207AP, 2208AP, 2209AP, 2210AP, 2211AP, 2212AP, 2213AP, 2214AP, 2215AP, 2216AP, 2217AP, 2218AP, 2218RS, 2219AP, 2220AP, 2221AP, 2222AP, 2223AP, 2224AP, 2225AP, 2226AP, 2227AP, 2228AP, 2229AP, 2230AP, 2231AP, 2232AP, 2233AP, 2234AP, 2235AP, 2236AP, 2237AP, 2238AP, 2239AP, 2240AP, 2241AP, 2242AP, 2243AP, 2244AP, 2245AP, 2246AP, 2248AP, 2249AP, 2250AP, 2251AP, 2252AP, 2253AP, 2254AP, 2255AP, 2256AP, 2258AP, 2259AP, 2260AP, 2261AP, 2267AP, A936TU, B1801TU, B1900, B1959TU, B1973TU, B2800, B2801-TU, B3800, B3813AP, B3827AP, C302, C302TU, C310TU, C501TU, C502TU, C503TU, C504TU, C506TU, C551TU, C552TU, C553TU, C554TU, C555TU, C556TU, C557TU, C558TU, C559TU, C560TU, C561TU, C562TU, C563TU, C564TU, C565TU, C566TU, C567TU, C582TU, C700T, C710TU, C731TU, C763, C774TU, C7xxTU, DV6000T, F503AU, F551AU, F573AU, M2000, M2000Z, M2001AP, M2001xx, M2002AP, M2003AP, M2004AP, M2005AP, M2006AP, M2007AP, M2008AP, M2009AP, M2010AP, M2011AP, M2012AP, M2013AP, M2014AP, M2015AP, M2016AP, M2017AP, M2018AP, M2019AP, M2020AP, M2021AP, M2022AP, M2023AP, M2024AP, M2025AP, M2026AP, M2027AP, M2028AP, M2029AP, M2030AP, M2031AP, M2032AP, M2033AP, M2034AP, M2035AP, M2036AP, M2037AP, M2038AP, M2039AP, M2040AP, M2041AP, M2042AP, M2043AP, M2044AP, M2045AP, M2046AP, M2047AP, M2048AP, M2049AP, M2050AP, M2051AP, M2052AP, M2053AP, M2054AP, M2055AP, M2099xx, M2200, M2201AP, M2201TU, M2202AP, M2202TU, M2203AP, M2204AP, M2205AP, M2206AP, M2207AP, M2208AP, M2209AP, M2210AP, M2211AP, M2212AP, M2213AP, M2214AP, M2215AP, M2216AP, M2217AP, M2218AP, M2219AP, M2220AP, M2221AP, M2222AP, M2223AP, M2224AP, M2225AP, M2226AP, M2227AP, M2228AP, M2229AP, M2230AP, M2231AP, M2232AP, M2233AP, M2234AP, M2235AP, M2236AP, M2237AP, M2238AP, M2239AP, M2240AP, M2241AP, M2242AP, M2243AP, M2244AP, M2245AP, M2253AU, M2256AU, M2259xx MV IUR, M2340AP, M2401XT, N2000, V2000, V2001AP, V2002AP, V2003AP, V2004AP, V2005AP, V2006AP, V2007AP, V2008AP, V2009AP, V2010AP, V2011AP, V2012AP, V2013AP, V2014AP, V2015AP, V2016AP, V2017AP, V2018AP, V2019AP, V2020AP, V2021AP, V2022AP, V2024AP, V2025AP, V2026AP, V2027AP, V2028AP, V2029AP, V2030AP, V2031AP, V2032AP, V2033AP, V2034AP, V2035AP, V2036AP, V2042AP, V2100, V2157AP, V2300, V2300T, V2300Z, V2311AP, V2325AP, V2340AP, V2398xx MV IUR, V2399xx, V2399XX, V2400T, V2402AU, V2414TU, V2418AU, V2433AU, V2566AP, V2602XT, V2606CU, V2627AU, V2649TS, V3000, V3000T, V3000Z, V3020, V3021, V3118AU, V3200, V3200TU, V3201AU, V3201TU, V3202AU, V3202TU, V3203AU, V3203TU, V3204AU, V3204TU, V3205TU, V3206TU, V3207TU, V3208TU, V3211TU, V3218TU, V3219TU, V3230AU, V3239AU, V3239TU, V3240AU, V3243TU, V3244TU, V3250TU, V3255TU, V3256TU, V3307, V3329TU, V4000, V4000xx MV IUR, V4001AP, V4002AP, V4002xx MV IUR, V4003AP, V4003xx MV IUR, V4004AP, V4004xx MV IUR, V4005xx, V4100, V4101AP, V4102AP, V4103AP, V4104AP, V4105AP, V4106AP, V4107AP, V4108AP, V4109AP, V4110AP, V4111AP, V4112AP, V4113AP, V4114AP, V4115AP, V4116AP, V4117AP, V4118AP, V4119AP, V4120TU, V4121TU, V4122TU, V4201TU, V4202TU, V4209TU, V4214, V4229TU, V5000, V5000T, V5099xx, V5100, V5100Z, V5101AU, V5102TU, V5104AU, V5108CU, V5200, V6000, V6000T, V6000Z, V6001AU, V6002AU, V6003AU, V6107AP, V6107TU, V6109AU, V6150TU, V6201AU, V6204AU, V6301, V6502, X1401AP,	L107	✗	✗
2158AP	L107	✗	P		
2866, 2867, 2868, 2869, 2870, 2871, 2887, 2888, 2890, 2891, 2892, 2893, 2894, 2895, 2896, 2897, 2898, 2899, 1500 Series, 2200, 2800, 2801, 2802, 2803, 2804, 2805, 2806, 2806AP, 2807, 2809, 2810, 2811, 2812, 2813, 2813AU, 2814, 2814AP, 2815, 2816, 2817, 2817AR, 2818, 2818AP, 2819, 2819AP, 2820, 2820AP, 2821, 2822, 2822AP, 2823, 2823AP, 2825, 2825AP, 2826, 2826TC, 2827, 2827AP, 2828, 2828AP, 2830, 2832, 2832AP, 2835, 2835AP, 2838, 2838AP, 2840, 2840TC, 2845, 2845AP, 2853, 2853AP, 2857, 2857AP, 2858, 2858AP, 2860, 2860AP, 2861, 2861AP, 2862, 2862AP, 2863, 2863AP, 2864, 2864AP, 2865, 2865AP, 2866AP, 2867AP, 2868AP, 2869AP, 2870AP, 2871AP, 2887AP, 2888AP, 2890AP, 2891AP, 2892AP, 2893AP, 2894AP, 2895AP, 2896AP, 2897AP, 2898AP, 2899AP, 2900, 2902, 2903, 2904, 2905, 2906, 2907, 2908, 300, 305, 900 Series, V1000, V1001AP, V1002AP, V1003AP, V1004AP, V1005AP, V1006AP, V1007AP, V1008AP, V1009AP, V1010AP, V1011AP, V1012AP, V1013AP, V1014AP, V1015AP, V1016AP, V1017AP, V1018AP, V1019AP, V1020AP, V1021AP, V1022AP,	L107	✗	T		



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APAB8AU	90W AC/DC - APMB9AU	75W AC APA02AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
Compaq	Presario	V1023AP, V1024AP, V1025AP, V1026AP, V1027AP, V1028AP, V1029AP, V1030AP, V1031AP, V1032AP, V1033AP, V1034AP, V1035AP, V1036AP, V1037AP, V1038AP, V1039AP, V1040AP, V1041AP, V1042AP, V1043AP, V1044AP, V1045AP, V1046AP, V1047AP, V1048AP, V1049AP, V1050AP, V1051AP, V1052AP, V1053AP, V1054AP, V1055AP, V1056AP, V1057AP, V1058AP, V1059AP, V1060AP, V1061AP, V1062AP, V1063AP, V1064AP, V1065AP, V1066AP, V1067AP, V1068AP, V1069AP, V1070AP, V1071AP, V1072AP, V1073AP, V1074AP, V1075AP, V1101AP, V1102AP, V1103AP, V1104AP, V1105AP, V1106AP, V1107AP, V1108AP, V1109AP, V1110AP, V1111AP, V1112AP, V1113AP, X1000, X1010, X1012, X1012QV, X1021AP, X1022AP, X1023AP, X1026AP, X1027AP, X1028AP, X1029AP, X1030, X1031AP, X1032AP, X1033AP, X1034AP, X1035AP, X1036AP, X1037AP, X1038AP, X1040AP, X1041AP, X1042AP, X1043AP, X1044AP, X1045AP, X1046AP, X1047AP, X1048AP, X1049AP, X1050AP, X1051AP, X1052AP, X1053AP, X1054AP, X1055AP, X1056AP, X1057AP, X1058AP, X1060AP, X1061AP, X1062AP, X1063AP, X1064AP, X1065AP, X1066AP, X1067AP, X1068AP, X1069AP, X1070AP, X1071AP, X1072AP, X1073AP, X1074AP, X1075AP, X1076AP, X1077AP, X1078AP, X1079AP, X1080AP, X1081AP, X1082AP, X1083AP, X1084AP, X1085AP, X1086AP, X1087AP, X1088AP, X1089AP, X1090AP, X1091AP, X1092AP, X1093AP, X1094AP, X1095AP, X1096AP, X1097AP, X1098AP, X1099AP, X1200, X1201AP, X1202AP, X1203AP, X1204AP, X1205AP, X1206AP, X1207AP, X1208AP, X1209AP, X1210AP, X1211AP, X1212AP, X1213AP, X1214AP, X1215AP, X1216AP, X1217AP, X1218AP, X1219AP, X1220AP, X1221AP, X1222AP, X1223AP, X1224AP, X1225AP, X1227AP, X1228AP, X1229AP, X1230AP, X1231AP, X1232AP, X1233AP, X1234AP, X1236AP, X1237AP, X1238AP, X1239AP, X1240AP, X1241AP, X1242AP, X1300, X1301AP, X1302AP, X1303AP, X1304AP, X1305AP, X1306AP, X1307AP, X1308AP, X1309AP, X1310AP, X1311AP, X1312AP, X1313AP, X1314AP, X1315AP, X1316AP, X1317AP, X1318AP, X1319AP, X1320AP, X1321AP, X1322AP, X1324AP, X1325AP, X1326AP, X1327AP, X1328AP, X1330AP, X1360, X1460, X1480, X1480xx, 1501AP, 1503AP, 1504AP, 1506AP, 1507AP, 1508AP, 1509AP, 1510AP, 1510TC, 1511AP, 1512AP, 1514AP, 1520AP, 1522AP, 1525AP, 1528AP, 1531AP, 1532AP, 1535AP, 1536AP, 1538AP, 1540AP, 1545AP, 1550AP, 1555AP, 1565AP, 1570AP, 1572AP, 1575AP, 1580AP, 910AP, 920AP, 921AP, 923AP, 925AP, 927AP, 930AP, 935AP, 940AP, 943AP, 945AP, 950AP, 955AP	L107	✘	T
		N1050V, V6002xx, V6500T, V6500Z, V6501AU, V6502AU, V6503AU, V6504AU, V6505AU, V6506AU, V6507AU, V6508AU	L107	✘	✘
		6715b, B1200, B1201TU, CQ40-418AX, CQ40-419AU, CQ41-226TX, CQ45-138TX, CQ60, CQ60-217TX, CQ60-302AU, CQ61-107TU, CQ61-115TU, CQ61-117TU, CQ61-311AX, CQ61-314TU, CQ61-319TX, CQ61-320TX, CQ61-405AX, CQ61-406TU, CQ61-409TU	L111	✘	✘
		1110, 2100, 1010, 1020, 1030, 1060, 1065, 1070, 1075, 1080, 1115, 1120, 1200 series, 1200AP, 1200T-12XL, 1200TC, 1200TH, 1200-XL106, 1200-XL110, 1201, 1201AP, 1201S, 1202, 1203, 1205, 1206R, 1207, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1219, 1220, 1232, 1234, 1235, 1236, 1237, 1238, 1240, 1242, 1244, 1245, 1246, 1247, 1250, 1252, 1255, 1256, 1257, 1260, 1262, 1263, 1266, 1267, 1270, 1272, 1273, 1274, 1275, 1277, 1278, 1279, 12XL, 12XL300B, 12XL400, 12XL401, 12XL404, 12XL410, 12XL420, 12XL423, 12XL426, 12XL427, 12XL430, 12XL500, 12XL501, 12XL504, 12XL505, 12XL526, 12XL527, 1400, 1400T, 1450, 14XL, 14XL240, 1600, 1600 series, 1600i, 1600S, 1610, 1611, 1621, 1622, 1625, 1626, 1640, 1645, 1655, 1670, 1680, 1681, 1682, 1685, 1687, 1688, 1690, 1692, 1693, 1694, 16XL, 1700, 1700 series, 1700T, 1701, 1702, 1702AP, 1703, 1704, 1705, 1705AP, 1710, 1710T, 1711, 1712, 1713, 1714, 1715, 1716, 1717, 1720, 1721, 1722, 1723, 1723AP, 1724, 1724TC, 1725, 1725TC, 1726, 1726TC, 17XL, 17XL260, 17XL360, 1800, 1800t, 1800XL180, 18XL, 18XL280, 18XL580, 2100 series, 2100AP, 2100Z, 2101AP, 2102AP, 2103AP, 2104AP, 2105AP, 2106AP, 2107AP, 2108AP, 2109AP, 2110AP, 2111AP, 2112AP, 2113AP, 2114AP, 2115AP, 2116AP, 2117AP, 2120AP, 2123AP, 2124AP, 2125AP, 2130AP, 2133AP, 2135AP, 2140AP, 2143AP, 2145AP, 2150AP, 2153AP, 2154AP, 2155AP, 2156AP, 2157AP, 2175, 2500, 2500 series, 2500AP, 2501, 2505AP, 2510AP, 2515AP, 2517, 2519, 2520AP, 2525AP, 2529, 2530AP, 2535AP, 2538AP, 2540AP, 2543AP, 2545AP, 2550AP, 2555AP, 2560AP, 2565AP, 2567AP, 2568, 2568AP, 2570, 2573AP, 2585, 2590, 2594, 2596, 2597, 2598, 2700, 2700 series, 2700T, 2700TC, 2700xx, 2701, 2702, 2710, 2710TC, 2711, 2711AP, 2711TC, 2712, 2715, 2716, 2720, 3000, 3005, 3015, 3017, 3019, 3020, 3080, 700, 700 series, 701, 702, 703, 703AP, 704, 705, 706, 709, 710, 710TC, 711, 71110, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 800, 800T, 801, 802, 803, 850	L106	✘	P
	X1001	L106	✘	T	
	Prosignia	170, 190	L107	✘	T
150		L106	✘	P	
Tablet	TC-1000, TC-1100	L107	✘	T	
Dell	Inspiron	1521, 1721, 1150, 1318 (Intel Graphic card), 1318 (NVIDIA Graphic card), 1420 (Intel Graphic card), 1420 (NVIDIA Graphic card), 1501, 1520 (Intel Graphic card), 1520 (NVIDIA Graphic card), 1525, 1526, 1545, 1720 (Intel Graphic card), 1720 (NVIDIA Graphic card), 300M, 500M, 510M, 5160, 6000, 600M, 630M, 6400, 640m, 700M, 710M, 8500, 8600, 9200, 9300, 9400, E1405, E1505, E1705	L109	✘	✘



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC -APA68AU	75W AC APA02AU	90W AC/DC -APA69AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
Dell	Inspiron	1200, 1300, 2200, 3000, 3200, 3500, 7000, B120, B130	L106	✗	P
		2500, 2600, 2650, 3700, 3800, 4000, 4150, 5000, 7500, 8000, 8100, 8200	✗	✗	S
	Inspiron Netbook	Mini 9, Mini 10, Mini 12	L108	✗	T
	Latitude	XT, 131L, ATG D630, ATG E6400, D400, D410, D420, D430, D500, D505, D510, D520, D530, D531, D600, D610, D620 (Intel Graphic card), D620 (NVIDIA Graphic card), D630 (Intel Graphic card), D630 (NVIDIA Graphic card), D630(Intel Graphic Card), D630(NVidia Graphic Card), D800, D810, D820, D830, E4200, E4300, E5400, E5500, E6400, E6500, L100, X1, X300, XFR D630	L109	✗	✗
		110L	L108	✗	P
		C400, C410, C500, C510, C600, C610, C640, C800, C810, CP, Cpi, CPT, CPx, CS/CSx, LM, X200	✗	✗	S
	Precision	M20, M2300, M2400, M4300, M60, M65, M70	L109	✗	✗
	Studio	1535 (ATI Graphic card), 1535 (Intel Graphic card), 1536 (ATI Graphic card), 1536 (Intel Graphic card), 1537 (ATI Graphic card), 1537 (Intel Graphic card), 1555, 1735, 1737	L109	✗	✗
	Vostro	1000, 1400, 1500, 1700, 1310 (Intel Graphic card), 1310 (NVIDIA Graphic card), 1400 (Intel Graphic card), 1400 (NVIDIA Graphic card), 1500 (Intel Graphic card), 1500 (NVIDIA Graphic card), 1510 (Intel Graphic card), 1510 (NVIDIA Graphic card), 2510, A840, A860	L109	✗	✗
XPS	M1210, M1330 (Intel graphic card), M1330 (Nvidia graphic card), M1530	L109	✗	✗	
Fujitsu	Amilo M	M1420, M7400	L106	✗	P
	Amilo Pro	V2000D, V8010D	L108	✗	✗
	FMV-BIBLO	FLX2H, LOOX S80B, LOOX S80B/W, LOOX S80C, LOOX S80C/W, LOOX T50E, LOOX T50E/W, LOOX T50G/W, LOOX T50H, LOOX T50J, LOOX T50K, LOOX T55G, LOOX T70E, LOOX T70G, LOOX T70H, LOOX T70HN, LOOX T70J, LOOX T70JN, LOOX T70K/T, LOOX T93B, LOOX T93B/W, LOOX T93C, LOOX T93C/W, MG12B, MG12B/C, MG12B/M, MG12C, MG12C/M, MG12D, MG13D, MG17D/A, MG50E, MG50G, MG50H, MG50HN, MG50K, MG50K/T, MG55E, MG70E, MG70E/ST, MG70G, MG70G/ST, MG70H, MG70K/T, MG75E, MG75G, MG75H, MG75H/ST, MG75HN, MG75K, MR16B, NB14B, NB14B/R, NB15B, NB15B/S, NB15B/T, NB16B, NB16B/M, NB16C, NB16C/A, NB16C/R, NB16C/ST, NB16C/T, NB16C/V, NB16CA, NB16CR, NB18B, NB18C, NB18C/T, NB18D, NB18D/D, NB18D/F, NB18D/L, NB18D/V, NB19D, NB19D/D, NB50E, NB50G, NB50H, NB50HN, NB50J, NB50JN, NB50K, NB53E, NB55E, NB55E/T, NB55G, NB55G/T, NB55H, NB55H/T, NB55J, NB55J/T, NB55K, NB55K/T, NB70E, NB70E/T, NB70G, NB70H/T, NB75G, NB75G/T, NB75H, NB75H/T, NB75HN, NB75HN/T, NB75J, NB75K/T, NB80J, NB80JN, NB80K, NB90J/T, NB90J/TS, NB90JN/T, NB90K/T, NB90K/TS, NB90KN/T, NH24C, NH24D, NH26C, NH28D, NH50E, NH70E, NH90E/T, NU, RS18D, RS18D/D, RS18D/ST, RS18D/T, RS50E/T, RS55E/T	L130 ☎ Freecall now for free tip!	N	✗
		A1010, A3110, Amilo L, C1010, C1020, C1110, C1211D, C1410, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2330, C2340, C3367, C6637, C6xx5, Cxxx7, E2010, E4010, E4010D, E6624, E6634, E6644, E6654, E6664, E66xx, E7010, E7110, E8010, E8010D, E8020, E8020D, E8110, E8210, N3510, N3511, N3520, N3530, N6110, N6210, N6220, S6130, S6410, S7010, S7010D, S7011, S7110, Stylistic ST4120, Stylistic ST4121, T4010, T4010D, T4020, T4210, T4220	L106	✗	P
	LifeBook	200, 270Dx, 280Dx, 400, 420D, 420Dx, 435Dx, 500, 520D, 520T, 530T, 531T, 535T, 535Tx, 555T, 555Tx, 565Tx, 585Tx, 585Tx1, 600, 635T, 635Tx, 635Tx1, 655Tx, 656Tx, 656Tx1, 675Tx, 690Tx, 700, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 900, 985Tx, 990Tx2, A4170, B112, B142, B2, B2130, B2131, B2175, B245x, B2545, B2562, B2566, B256x, B2610, B2620, B2630, B3010D, B3020, B3020D, B5010, B6110D, B6210, C340, C350, C352, C353, C360, C4120, C4235, C5130, C5235, C6177, C6320, C6330, C6525, C6535, C6537, C6547, C6556, C6557, C6577, C6581, C6591, C6611, C6631, C6651, C7631, C7651, C7661, Celsius Mobile H, E330, E335, E340, E342, E350, E351, E360, E362, E370, E380, E5140, E5320, E5520, E6150, E6520, E6530, E6540, E6541, E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595, Exxx5, L440, L470, P1000, P1032, P1035, P1110, P1120, P1510D, P1610, P2000, P2040, P2046, P2110, P2120, P5010, P5010D, P5020, P5020D, P7010, P7010D, P7120, P7120D, P7230, Q2010, S2010, S2020, S2110, S4510, S4542, S4546, S4572, S5582, S6010, S6110, S6120, S6120D, S6210, S6220, S6230, S6231, S6240, ST5030, ST5030D, ST5031, ST5031D, ST5032, ST5032D, Stylistic 3400, Stylistic 3500, Stylistic CT2020, Stylistic LT C-500, Stylistic LT P-600, Stylistic ST4110, Stylistic ST4110P, Stylistic ST4120P, Stylistic ST4121P, Stylistic ST5010, Stylistic ST5010D, Stylistic ST5011, Stylistic ST5011D, Stylistic ST5020, Stylistic ST5020D, Stylistic ST5021, Stylistic ST5021D, Stylistic ST5022, Stylistic ST5022D, T3010, T3010D, U820	L130 ☎ Freecall now for free tip!	N	✗



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - APA68AU 90W AC/DC - APA69AU	75W AC APA02AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
Gateway	Gateway	400SD4, 400VTX, 4012GZ, 4024GZ, 4026GZ, 4028GZ, 405E, 405X, 450ROG, 450SX4, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 600YG2, 600YGR, M305, M500	L106	✗	P
	Solo	1100 Series, 1150, 1200, 1400, 1450, 2100 series, 2150 Series, 2200 series, 2300 series, 2500 series, 2550 Series, 3100 Series, 3150 Series, 5100 series, 5150 Series, 5300, 5350, 9100 Series, 9150, 9300 Series, 9500, 9550	L106	✗	P
HP	Business Tablet	TC4200	L107	✗	T
		TC4400	L111	✗	✗
	Business Thin Client	2533t, 4310t, 6720t	L111	✗	✗
	EliteBook	2530p, 2540p, 2730p, 2740p, 6930p, 8440p (Intel Graphics), 8440p (NVIDIA Graphics), 8440w (Intel Graphics ONLY), 8540p (Intel Dual-core processor ONLY)	L111	✗	✗
	Envy	13-1006TX, 13-1008TX, 13-1101TX, 13-1102TX	L111	✗	✗
	HP	510, 530, 550, L2000, L2005A3, L2005A4, L2098XX, L2099XX	L107	✗	T
		520, 540, 541, G60t, G70t	L111	✗	✗
	HP Compaq Business	6520s (Intel Graphic card), 6720s, NC4000, NC4010, NC4200, NC6000, NC6120, NC6200, NC6220, NC6230, NC8000, NW8000, NX5000, NX6100, NX6110, NX6115, NX6120, NX6125, NX7000, NX7010, NX7200, NX9020, NX9030, NX9040	L107	✗	T
		6520s (ATI Graphic card), 6820s, NX8220	L107	✗	✗
		2230s, 2510p, 2710p, 6510b, 6515b, 6530b, 6530s (Intel Graphics), 6531s (ATI Graphics), 6535b, 6535s, 6710b, 6710s, 6712b, 6715b, 6715s, 6715sb, 6730b, 6730s, 6735b, 6735s, 6830s, 6910p, 8510p, 8510w, NC2400, NC4400, NC6140, NC6320, NC6400 (ATI Graphic card), NC6400 (Intel Graphic Card), NC6440, NC8230, NC8430, NW8240, NW8440, NX6310, NX6320, NX6325, NX7300, NX7400, NX8420, NX9420	L111	✗	✗
		NX9000, NX9005, NX9008, NX9010	L106	✗	P
	Mini Netbook	2133 Mini-Note, 2140	L111	✗	✗
1101, 2102, 1000 series, 1000 Vivienne Tam series, 1001TU, 110-1004TU, 110-1008TU, 110-1100TU, 110-1106TU, 110-1156TU, 1109TU, 210-1015TU, 210-1016TU, 210-1017TU, 210-1018TU, 210-1020TU		L125 ☎ Freecall now for free tip!	✗	✗	
Omnibook	2000, 2100, 2103, 2105, 300, 3000, 3100, 3101, 4000, 4000C, 4100, 4101, 4103, 4105, 4150, 4150B, 425, 430, 500, 5000, 510, 530, 5500, 5700, 6000, 6000B, 6000C, 6100, 7100, 7103, 7150, 900, 900B, N3000, VT6200, XE, XE 4400 BTO, XE2, XE2-DB, XE2-DC, XE2-DD, XE2-DI, XE3, XE3B, XE3C, XE3-GD, XE3-GF, XE4100, XE4200, XE4400, XE4500, XE-DA, XT1000, XT1500, XT6050, XT6200	L106	✗	P	
Pavillion	DV1000, DV1001AP, DV1002AP, DV1003AP, DV1004AP, DV1005AP, DV1006AP, DV1007AP, DV1008AP, DV1009AP, DV1010AP, DV1013AP, DV1014AP, DV1015AP, DV1016AP, DV1017AP, DV1018AP, DV1019AP, DV101EAP, DV1020AP, DV1021AP, DV1022AP, DV1023AP, DV1024AP, DV1025AP, DV1026AP, DV1027AP, DV1029AP, DV1030AP, DV1031AP, DV1100, DV1101AP, DV1102AP, DV1103AP, DV1104AP, DV1105AP, DV1106AP, DV1107AP, DV1109AP, DV1110AP, DV1111AP, DV1112AP, DV1113AP, DV1115AP, DV1116AP, DV1117AP, DV1118AP, DV1119AP, DV1120AP, DV1121AP, DV1122AP, DV1123AP, DV1124AP, DV1125AP, DV1127AP, DV1128AP, DV1129AP, DV1130AP, DV1131AP, DV1132AP, DV1133AP, DV1134AP, DV1135AP, DV1136AP, DV1137AP, DV1139AP, DV1300, DV1301XX MV IUR, DV1302XX MV IUR, DV1311AP, DV1312AP, DV1313AP, DV1314AP, DV1315AP, DV1316AP, DV1317AP, DV1318AP, DV1319AP, DV1320AP, DV1321AP, DV1324AP, DV1325AP, DV1326AP, DV1327AP, DV1328AP, DV1329AP, DV1330AP, DV1331AP, DV1332AP, DV1333AP, DV1334AP, DV1335AP, DV1336AP, DV1338AP, DV1339AP, DV1340AP, DV1341AP, DV1342AP, DV1343AP, DV1344AP, DV1345AP, DV1346AP, DV1347AP, DV1348AP, DV1349AP, DV1350AP, DV1351AP, DV1352AP, DV1353AP, DV1354AP, DV1355AP, DV1356AP, DV1357AP, DV1358AP, DV1359AP, DV1360AP, DV1361AP, DV1362AP, DV1362TU, DV1363AP, DV1364AP, DV1365AP, DV1366AP, DV1367TU, DV1368TU, DV1369TU, DV1370TU, DV1371TU, DV1372TU, DV1373TU, DV1374TU, DV1375TU, DV1376TU, DV1379TU, DV1380TU, DV1381TU, DV1382TU, DV1383TU, DV1384TU, DV1385TU, DV1386TU, DV1387TU, DV1388TU, DV1389TU, DV1390TU, DV1391TU, DV1392TU, DV1393TU, DV1394TU, DV1395TU, DV1396TU, DV1399XX MV IUR, DV1600, DV1610TN, DV1738OD, DV2000, DV2000Z, DV2002TU, DV2017TU, DV2020TX, DV2023, DV2023TU, DV2029TU, DV2036TU, DV2045TU, DV2-1001AU, DV2111TX, DV2112TX, DV2133, DV2401TU, DV2402TU, DV2403TU, DV2404TU, DV2405TU, DV2501xx, DV2502TU, DV2505TU, DV2506xx, DV2508TU, DV2509TU, DV2510TU, DV2511TU, DV2512TU, DV2513TU, DV2514TU, DV2515TU, DV2516TU, DV2517TU, DV2518TU, DV2519TU, DV2520TU, DV2521TU, DV4000xx MV IUR, DV4001AP, DV4001xx MV IUR, DV4002AP, DV4003AP, DV4004AP, DV4004xx MV IUR, DV4005AP, DV4005xx MV IUR, DV4006AP, DV4006xx MV IUR, DV4007AP,	L107	✗	✗	



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - APA68AU 90W AC/DC - APF689AU	75W AC APA02AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
HP	Pavillion	DV4007xx MV IUR, DV4008AP, DV4009AP, DV4010AP, DV4011AP, DV4012AP, DV4013AP, DV4014AP, DV4015AP, DV4016AP, DV4017AP, DV4018AP, DV4019AP, DV4020AP, DV4021AP, DV4022AP, DV4023AP, DV4024AP, DV4025AP, DV4026AP, DV4100, DV4114, DV4117AP, DV4121AP, DV4126AP, DV4201TU, DV4201TX, DV4202TU, DV4202TX, DV4203TU, DV4203TX, DV4204TU, DV4204TX, DV4205TX, DV4206TU, DV4206TX, DV4207TU, DV4207TX, DV4208TX, DV4209TX, DV4210TX, DV4211TX, DV4212TX, DV4213TX, DV4214TX, DV4215TX, DV4216TX, DV4217TX, DV4218TX, DV4219TX, DV4220TX, DV4221TX, DV4222TX, DV4223TX, DV4224TX, DV4225TX, DV4288, DV4420, DV5000, DV5000T, DV5100, DV5101TU, DV5101TX, DV5102TU, DV5102TX, DV5103TX, DV5104TU, DV5104TX, DV5105TU, DV5105TX, DV5106TX, DV5107TX, DV5108TX, DV5109TX, DV5110TX, DV5112TX, DV5113TX, DV5114TX, DV5115TX, DV5116TX, DV5117TX, DV5118TX, DV5120TX, DV5121TX, DV5123TX, DV5124TX, DV5125TX, DV5126TX, DV5127TX, DV5128TX, DV5129TX, DV5130TX, DV5131TX, DV5196XX, DV5197XX, DV5200, DV5200TU, DV5200TX, DV5201TU, DV5201TX, DV5202TU, DV5202TX, DV5203TU, DV5203TX, DV5204TU, DV5204TX, DV5205TX, DV5206TU, DV5206TX, DV5207TX, DV5208TX, DV5209TX, DV5210TX, DV5211TX, DV5212TX, DV5213TX, DV5214TX, DV5215TX, DV5216TX, DV5217TX, DV5218TX, DV5219TX, DV5220TX, DV5221TX, DV5222TX, DV5223TX, DV5224TX, DV5225TX, DV5226TX, DV5227TX, DV5228TX, DV5229TX, DV5230TX, DV5231TX, DV5232TX, DV5233TX, DV5235TX, DV5236TX, DV5237TX, DV6102OD, DV6128TU, DV6131OD, DV6200, DV6204AU, DV6501TU, DV6502TU, DV6503TU, DV6504TU, DV6506TU, DV6507TU, DV6508TU, DV6509TU, DV6599xx, DV6700T(Intel Graphic card), DV8000xx, DV8013xx, DV8040xx, DV8099xx, DV8200, DV8211TX, DV8218, DV8219, DV8308, DV8310TX, DV9598xx, DV9599xx, TX2-1015AU, DV2000T, DV2024TX, DV2040TX, DV2085, DV2113TU, DV2123TU, DV2222TX, DV2305TU, DV2308TX, DV2503xx, DV2521TX, DV2522TX, DV2529TX, DV2530TX, DV2533TX, DV2538TX, DV2609TX, DV2619TX, DV2632TX, DV2633TX, DV2637TX, DV2700TU (NVIDIA Graphic card), DV2701TX Special Edition, DV2739TX Special Edition, DV2740TX Special Edition, DV2753TX Special Edition, DV2754TX, DV2754TX Special Edition, DV2758TX Special Edition, DV2762TX Special Edition, DV2765TX Special Edition, DV2766TX Special Edition, DV2807TX, DV2808TX, DV2809TX, DV2813TX, DV2814TX, DV2817TX, DV2819TX, DV2820TX, DV2823TX, DV2825TX, DV2827TX, DV2828TX, DV2835TX, DV4000, DV6000, DV6000Z, DV6001XX, DV6113TX, DV6116TX, DV6121TX, DV6122TX, DV6129TX, DV6201TU, DV6207TX, DV6218TX, DV6221TX, DV6302TU, DV6304TX, DV6306TX, DV6404TU, DV6500, DV6500T, DV6500Z, DV6501TX, DV6502TX, DV6503TX, DV6504TX, DV6505TU, DV6505TX, DV6506TX, DV6507TX, DV6509TX, DV6510TX, DV6511TX, DV6512TX, DV6513TX, DV6514TX, DV6515TX, DV6516TX, DV6517TX, DV6518TX, DV6519TX, DV6520TX, DV6521TX, DV6522TX, DV6523TX, DV6524TX, DV6525TX, DV6526TX, DV6527TX, DV6528TX, DV6529TX, DV6531TX, DV6533TX, DV6534TX, DV6535TX, DV6536TX, DV6539TX, DV6540TX, DV6541TX, DV6542TX, DV6543TX, DV6544TX, DV6545TX, DV6546TX, DV6547TX, DV6548TX, DV6597xx, DV6598xx, DV6601AX, DV6614TX, DV6617TX, DV6700T(NVIDIA Graphic card), DV6709AX, DV6721TX, DV6724TX, DV6733TX, DV6746TX, DV6755TX, DV6757TX, DV6796TX, DV6835, DV6837TX, DV6838TX, DV8000, DV9000, DV9000T, DV9000Z, DV9001xx, DV9003xx, DV9007, DV9007TX, DV9008TX, DV9018, DV9018TX, DV9079, DV9095xx, DV9098xx, DV9203TX, DV9205TX, DV9218TX, DV9303TX, DV9304, DV9307TX, DV9500T, DV9500Z, DV9501TX, DV9502TX, DV9503TX, DV9504TX, DV9505TX, DV9506TX, DV9507TX, DV9508TX, DV9509TX, DV9511TX, DV9512TX, DV9513TX, DV9514TX, DV9516TX, DV9517TX, DV9518TX, DV9519TX, DV9520TX, DV9521TX, DV9596xx, DV9613TX, DV9615TX, DV9630, DV9700, DV9700T, DV9722TX, DV9724TX, DV9725TX, DV9748TX, DV9822TX, TX1219AU	L107	✗	✗
		ZE2001AP, ZE2001xxMV IUR, ZE2002AP, ZE2003AP, ZE2004AP, ZE2005AP, ZE2006AP, ZE2007AP, ZE2008AP, ZE2009AP, ZE2009XX MV IUR, ZE2009xxMV IUR, ZE2010AP, ZE2011AP, ZE2012AP, ZE2013AP, ZE2014AP, ZE2015AP, ZE2016AP, ZE2017AP, ZE2018AP, ZE2019AP, ZE2020AP, ZE2200, ZE2200T, ZE2200Z, ZE2201AP, ZE2201XX MV IUR, ZE2201xxMV IUR, ZE2202AP, ZE2203AP, ZE2204AP, ZE2205AP, ZE2206AP, ZE2207AP, ZE2208AP, ZE2209AP, ZE2209XX MV IUR, ZE2209xxMV IUR, ZE2210AP, ZE2211AP, ZE2212AP, ZE2296XX MV IUR, ZE2296xxMV IUR, ZE2297XX MV IUR, ZE2297xxMV IUR, ZE2298XX MV IUR, ZE2298xxMV IUR, ZE2299XX MV IUR, ZE2299xxMV IUR, ZE2401XT, ZE4901 MV IUR, ZE4902 MV IUR, ZE5526AP, ZT3050AP, ZT3301AP, ZV5203AP	L107	✗	P
		4316, 3010AP, 3011AP, 4523, 6100 Series, DM1-1001TU, DM1-1002TU, DM1-1003TU, DM1-1004TU, DM1-1005TU, DM1-1006TU, DM1-1007TU, DM1-1008TU, DM1-1009TU, DM1-1010TU, DM1-1011TU, DM1-1012TU, DM1-1013TU, DM1-1014TU, DM1-1015TU, DM1-1016TU, DM1-1017TU, DM1-1018TU, DM1-1019TU, DM1-1020TU, DM1-1021TU, DM1-1022TU, DM1-1023TU, DM1-1024TU, DM1-1103TU, DM3-1011TU, DM3-1016AX, DM3-1022TX, DM3-1033TX, DM3-1104TX, DM3-1105TX, HDX9003TX, HDX9004TX, TX1000, TX1001AU, TX1001xx, TX1002AU, TX1002xx, TX1003AU, TX1003xx, TX1004AU, TX1005AU, TX1006AU, TX-1007AU, TX1008AU, TX1014AU, TX1030IA, TX2011AU, TX2500Z, TX2502AU, TX2503AU, V5022AP, ZT3000, ZT3010, ZT3010AP, ZT3011AP, ZT3012AP, ZT3013AP, ZT3014AP, ZT3015AP, ZT3016AP, ZT3017AP, ZT3018AP, ZT3019AP, ZT3020, ZT3020AP, ZT3021AP, ZT3022AP, ZT3023AP, ZT3024AP, ZT3025AP, ZT3026AP, ZT3027AP, ZT3028AP, ZT3029AP, ZT3030AP, ZT3031AP, ZT3032AP, ZT3033AP, ZT3034AP, ZT3035AP, ZT3036AP, ZT3037AP, ZT3038AP, ZT3039AP, ZT3040AP, ZT3041AP, ZT3043AP, ZT3044AP, ZT3045AP, ZT3046AP, ZT3047AP, ZT3048AP, ZT3049AP, ZT3050AP, ZT3051AP, ZT3201AP, ZT3202AP, ZT3203AP, ZT3204AP, ZT3205AP, ZT3206AP, ZT3207AP, ZT3208AP, ZT3209AP, ZT3211AP, ZT3212AP, ZT3250xx, ZT3280, ZT3302, ZT3340, ZT3350, ZT3380	L107	✗	T
		DV3-1000 series, DV3-2002TU, DV3-2007TX, DV3504TX, DV3505TX, DV3506TX, DV3507TX, DV3522TX, DV3528TX, DV3529TX, DV3530TX, DV3534TX, DV3535TX, DV3539TX, DV3540TX, DV3Z series, DV4-1000, DV4-1004TU, DV4-1015TX, DV4-1016TX, DV4-1041TX, DV4-1048TX, DV4-1049TX, DV4T-1000, DV5-1004TX, DV5-1007TX, DV5-1009TX, DV5-1010TX, DV5-1019TX, DV5-1020TX, DV5-1045TX, DV5-1046TX, DV5-1050TX, DV5-1053TX, DV5-1054TX, DV5-1055TX, DV5-1140TX, DV6-1107AX, DV6-1129TX, DV6-1130TX, DV6-1207AX, DV6-1214AX, DV6-1244TX, DV6-1246TX, DV6-1247TU, DV6-2113TX, DV6-2114TX, DV6-2120TX, DV6-2145TX, DV6-3006TX, DV7-1000, DV7-1002TX, DV7-1005TX, DV7-1014TX, DV7-1015TX, DV7-1019TX, DV7-1026TX, DV7-1104TX, DV7-1105TX, DV7-1107TX, DV7-2012TX, DV7-2014TX, DV7-2022TX, DV7-3105TX, DV7-3107TX, DV7Z-1000	L111	✗	✗



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP468AU	75W AC APA02AU	90W AC	90W AC APA03AU
90W AC/DC - AP469AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
HP	Pavillion	2105, 3101, 4101, 4103, 4105, 5159, N3110, N3150, N3190, N3210, N3215, N3220, N3250, N3270, N3290, N3295, N3310, N3330, N3350, N3370, N3380, N3390, N3402, N3410, N3438, N3478, N3490, N5000 BTO, N5124, N5125, N5130, N5135, N5140, N5150, N5159, N5170, N5190, N5195, N5210, N5221, N5240, N5241, N5250, N5261, N5270, N5271, N5290, N5295, N5310, N5311, N5331, N5340, N5341, N5350, N5351, N5361, N5371, N5381, N5390, N5401, N5402, N5402L, N5412, N5415, N5420, N5421, N5421L, N5422, N5422L, N5425, N5430, N5431L, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5451, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N5511L, N5584, N6190, N6195, N6300 BTO, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6402, N6403, N6404, N6490, XF125, XF145, XF235, XF255, XF315, XF325, XF328, XF335, XH136, XH156, XH176, XH215, XH216, XH226, XH355, XH365, XH395, XH455, XH485, XH525, XH535, XH545, XH555, XH575, XH625, XH675, XT115, XT118, XT125, XT128, XT155, XT178, XT183, XT188, XT236, XT276, XT345, XT375, XT395, XT412, XT4345QV, XT512, XT5300, XT5335QV, XT5366, XT5377, XT5377QV, XT545, XT555, XT565, XT575, XT585, XT595, XU/ZU BTO, XU155, XZ133, XZ148, XZ163, XZ168, XZ185, XZ275, XZ295, XZ335, XZ355, ZE1000, ZE1110, ZE1115, ZE1145, ZE1201, ZE1202, ZE1210, ZE1230, ZE1250, ZE1260, ZE4000, ZE4101, ZE4102, ZE4103, ZE4105, ZE4111, ZE4115, ZE4120, ZE4123, ZE4125, ZE4130, ZE4133, ZE4140, ZE4145, ZE4200, ZE4201, ZE4202, ZE4204, ZE4206, ZE4207, ZE4208, ZE4209, ZE4210, ZE4211, ZE4214, ZE4218, ZE4219, ZE4220, ZE4221, ZE4222, ZE4224, ZE4228, ZE4229, ZE4230, ZE4231, ZE4232, ZE4234, ZE4236, ZE4239, ZE4240, ZE4241, ZE4251, ZE4258, ZE4261, ZE4268, ZE4271, ZE4274, ZE4278, ZE4281, ZE4282, ZE4284, ZE4288, ZE4292, ZE4294, ZE4298, ZE4301, ZE4305, ZE4307, ZE4308, ZE4310, ZE4311, ZE4312, ZE4313, ZE4314, ZE4315, ZE4316, ZE4317, ZE4318, ZE4319, ZE4320, ZE4321, ZE4323, ZE4325, ZE4330, ZE4332, ZE4333, ZE4334, ZE4335, ZE4336, ZE4345, ZE4347, ZE4348, ZE4349, ZE4351, ZE4352, ZE4353, ZE4354, ZE4355, ZE4356, ZE4357, ZE4360, ZE4365, ZE4367, ZE4375, ZE4384, ZE4385, ZE4386, ZE4400, ZE4401, ZE4402, ZE4410AP, ZE4412AP, ZE4413AP, ZE4414AP, ZE4427, ZE4500, ZE4520AP, ZE4521AP, ZE4522AP, ZE4523AP, ZE4540, ZE4546, ZE4547, ZE4551, ZE4560, ZE4600, ZE4610, ZE4700, ZE4800, ZE5000, ZE5030, ZE5155, ZE5160, ZE5165, ZE5170, ZE5185, ZE5190, ZE5200, ZE5207, ZE5217, ZE5228, ZE5232, ZE5236, ZE5238, ZE5240, ZE5242, ZE5244, ZE5250, ZE5252, ZE5258, ZE5262, ZE5270, ZE5279, ZE5300, ZE5320AP, ZE5345, ZE5375, ZE5385, ZE5395, ZE5400, ZE5470, ZE5490, ZE5500, ZE5515AP, ZE5575, ZE5600, ZE5603AP, ZE5604, ZE5604AP, ZE5605AP, ZE5608AP, ZE5611AP, ZE5612AP, ZE5613AP, ZE5616AP, ZE5620, ZE5700, ZE5749, ZT1000-IB BTO, ZT1114, ZT1120, ZT1121, ZT1121S, ZT1122, ZT1122S, ZT1125, ZT1130, ZT1131, ZT1131S, ZT1132, ZT1132S, ZT1135, ZT1141, ZT1142, ZT1145, ZT1150, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1170, ZT1171, ZT1172, ZT1175, ZT1180, ZT1181, ZT1182, ZT1185, ZT1190, ZT1192, ZT1201, ZT1201S, ZT1210, ZT1211, ZT1213, ZT1230, ZT1231S, ZT1233, ZT1235, ZT1243, ZT1250, ZT1260, ZT1261, ZT1270, ZT1271, ZT1290, ZT1331, ZU1155, ZU1175, ZU175	L106	✘	P
	ProBook	4310s (ATI Graphics), 4310s (Intel Graphics), 4320s (ATI Graphics), 4320s (Intel Graphics), 4410s, 4411s, 4415s, 4416s, 4420s (ATI Graphics), 4420s (Intel Graphics), 4510s (ATI Graphics), 4510s (Intel Graphics), 4515s (ATI Graphics HD 3200), 4515s (ATI Graphics HD 4330), 4710s, 5310m, 6440b (ATI Graphics), 6440b (Intel Graphics), 6445b, 6545b	L111	✘	✘
	Special Edition	L2000, L2005A3 MV IUR, L2005A4 MV IUR, L2098XX MV IUR, L2099XX MV IUR	L107	✘	T
	TouchSmart	TX2- series, TX2z series, TX2-1301AU, TX2-1304AU, TX2-1305AU, TX2-1307AU, TX2-1308AU, TX2-1310AU, TX2-1312AU, TX2-1314AU, TX2-1316AU, TX2-1322AU, TX2-1323AU, TX2-1325AU, TX2-1326AU	L107	✘	T
	TM2-1001TX, TM2-1002TX, TM2-1004TX, TM21005TX, TM2-1007TX, TM2-1008TX, TM2-1009TX, TM2-1012TX, TM2-1013TX, TM2-1014TX, TM2-1018TX, TM2T-1000 CTO	L111	✘	✘	
IBM/ Lenovo	3000	C100, C200, C205, N100 (Intel Graphic card), N100 (NVIDIA Graphic card), N200 (Intel Graphic card), N200 (NVIDIA Graphic card), V100, V200	L112	✘	R
		Y410	L106	✘	P
	IdeaPad	U110, U330, Y430, Y510, Y530, Y650, Y710, Y730	L106	✘	P
	IdeaPad Netbook	S10, S10e	L106	✘	P
	ThinkPad	240, 240X, 290, 365, 365XD, 380, 380D, 380E, 380ED, 380XD, 380Z, 385, 385D, 385ED, 385XD, 390, 390E, 390X, 560, 560E, 560X, 560Z, 570, 600, 600E, 600X, 701, 770, 770E, 770ED, 770X, 770Z, A20, A20m, A20p, A21, A21e, A21m, A21p, A22, A22e, A22m, A22p, A30, A30p, A31, A31p, A50, A50p, A51p, i1200, i1300, i1400-2621, i1500-2621, i1720, i1721, R30, R31, R32, R40, R40e, R50, R50e, R50p, R51, R51e, R52, T20, T21, T22, T23, T30, T40, T40p, T41, T41p, T42, T42p, T43, T43p, TransNote, X Series Tablet, X20, X21, X22, X23, X24, X30, X31, X32, X40, X41, X41 Tablet	L105	P	✘
	G50, R400, R500, R60, R60e, R61 (Intel Graphic card), R61 (NVIDIA Graphic card), R61e, R61i, SL300 (Intel Graphic card), SL300 (NVIDIA Graphic card), SL400 (Intel Graphic card), SL400 (NVIDIA Graphic card), SL500 (Intel Graphic card), SL500 (NVIDIA Graphic card), T400 (Intel Graphic card), T400 (NVIDIA Graphic card), T500 (ATI Graphic card), T500 (Intel Graphic card), T60 (ATI Graphic card), T60 (Intel Graphic card), T60p, T61 (Intel Graphic card), T61 (NVIDIA Graphic card), T61p (Intel Graphic card), T61p (NVIDIA Graphic card), W500, X200, X200S, X300, X301, X60, X60 Tablet, X60s, X61 Tablet, X61s, X61t, Z60m, Z60t, Z61e, Z61m, Z61p, Z61t	L112	✘	R	



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APA68AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - APMB9U			

Manufacturer	Model Name	Series	Tip	Tip	Tip
IBM/ Lenovo	ThinkPad	1400-2611, 1500-2611, 310, 310D, 310E, 310ED	L106	✗	U
	ThinkPad Reserve	Cingular Edition, Verizon Edition	L112	✗	R
Leader Computers	COMPANION 210	Z96SP	L106	✗	✗
	COMPANION 212	Z96SP	L106	✗	✗
	COMPANION 214	Z96SP	L106	✗	✗
	EX600	MS-1636	L106	✗	✗
	EX620	MS-1674	L106	✗	✗
	GX620	MS-1651 (90 Watt version only)	L106	✗	✗
	M670	MS-1632	L106	✗	✗
	U100	NO11	L106	✗	✗
	VR601	MS-163C	L106	✗	✗
	VR630	MS-1672	L106	✗	✗
	VR705	MS-171F	L106	✗	✗
LG	F1	F1-2224A, F1-2226A	L107	✗	✗
	LE Series	LE50-5	L107	✗	✗
	LM Series	LM50, LM60 Express	L107	✗	✗
	LS Express	LS55, LS70	L108	✗	T
	LS Series	LS70-FLA4PA	L107	✗	✗
	LS Series	LS50-1, LS50-2, LS50-3, LS50-4, LS50-5, LS50-UK2A, LU-20 Tablet	L108	✗	T
	LT Series	LT19	L108	✗	T
	LW Series	LW20-22, LW40, LW60, LW65, LW70, LW75, LW80	L107	✗	✗
	Netbook	X110	L106	✗	P
Macron	Macron	M363C, M540G, M540N, M550G, M550N, M551N, NW120, NW150, NX150	L105	P	✗
MSI	Netbook	EX300-018US, EX300-024US, EX620-IWIUS, EX625-227US, GT627-216US, GT627-218US, GX620-001US, GX620-038US, GX620-098US, PR201-013US, PR201-019US, PR201-Blue, PR201-Pink, PX600-008US, VR220-017US, VR601, VR705, X320, X340-021US, X340-023US	L106	✗	✗
	Wind Netbook	U100, U120, U90	L106	✗	✗



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APA68AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - AP1639U			

Manufacturer	Model Name	Series	Tip	Tip	Tip
NEC	LaVie	C Series, F Series, G Series, J Series, L Series, M Series, ME Series, N Series, Pro Series, T Series	L106	✗	P
	Pocket Gear	MC/PG5000, MC/PG7000	L106	✗	P
	Ready	220T, 230T, 330T, 340T, 360T, 440T	L106	✗	P
	Versa	2400, 2500, 2500CD, 2505, 2530, 4000, 4000 Series, 4000C, 4000D, 4000Hs, 4050C, 4050D, 4050H, 4080H, 4200, 4230, 500, 5000, 5060, 5060X, 5080, 5080X, 550D, A2100, C140, C150, C160, E120, E200, E2000, E3100, E3100-1812DW, E3100-1813DR, E600, E6000, E6000X, E6200, E6200-1703DR, E6210, E6210-1604DR, E6210-1627DR, E6210-1809DR, E6210-1810DR, E6210-1811DR, E6300, E6300-1504DR, E6300-1803DR, E6300-2201DR, E6310, E6310-2000DR, E680, FM320, FM500, FP520, FS800, IGO3000, IGO5000, IGO6000, L2100, L2100-1605DR, L2100-1606DR, L2100-1803DR, L2200-1802DR, L320, M300, M320, M3210, M440, M450, M500, M54, M540, P440, P520, P600, P700, P7200, P7200-1607DR, P7200-1800DR, P9110, P9110-1500DR, P9110-1800DR, P9110-2203DR, Premium, S1100, S800, S820, S940, S970, T400, T400S820, VersaNote, VX	L106	✗	P
	Versa	2000C, 2000D, 2205C, 2250, 6000, 6000H, 6010H, 6030H, 6030X, 6050 Series, 6050MH, 6050MT, 6050MX, 6060, 6200 Series, 6200MX, 6200NT, 6220, 6230, 6260	✗	✗	S
	VersaPro	VJ13M/AF-T, VJ13M/DF-R, VJ13M/RF-R, VJ13M/RX-R, VJ16F/RF-R, VJ16F/RX-R, VJ17F/AF-T, VJ17F/AG-T, VJ17F/DF-R, VJ17F/DG-R, VJ18F/RF-R, VJ20F/AE-T, VJ20F/AF-T, VJ20F/AG-T, VJ20F/DF-R, VJ20F/DG-R, VY13M/AF-T, VY13M/DF-R, VY13M/EF-R, VY13M/EX-R, VY13M/RF-R, VY13M/RX-R, VY16F/EF-R, VY16F/EX-R, VY16F/RF-R, VY16F/RX-R, VY17F/AF-T, VY17F/AG-T, VY17F/DF-R, VY17F/DG-R, VY18F/RF-R, VY20F/AE-T, VY20F/AF-T, VY20F/AG-T, VY20F/DF-R, VY20F/DG-R	L106	✗	P
	VersaPro NX	LW23C/52, LW23D, LW26H, LW30H, LW33H	L106	✗	P
Optima	Centoris	25911, E+ Series, EF6C, EW1, EW2G, F Series, G Series, L2400, TW3, V470, V662, V670, V862, V870, W Series, ZW1, ZW9	L106	✗	P
	ProLite	K Series	L108	✗	T
Packard Bell	EasyNote	1800DR, BG46, C16, C3, MB88-003, MX37-U-041, R8, SB88, XS20	L106	✗	P
		G5	L108	✗	T
Panasonic	Toughbook	52, 74, CF19, CF29, CF30, CF50, CF51, CF73, CFR1, CFR4, CFR7, CFT1, CFT2, CFW2, CFW4, T4, T5, T7, T8, W5, W7, W8, Y4, Y5, Y7	L105	P	✗
		CFV21, CFV21P	L110	✗	N
	Toughbook Netbook	CF01, CF11, CF17, CF170, CF25, CF27, CF270, CF28, CF33, CF34, CF35, CF37, CF370, CF380, CF41, CF45, CF47, CF48, CF61, CF62, CF63, CF71, CF72, CFM34, CFR, CFT, CFV25, CFV41	L130 © Freecall now for free tip!	N	✗
Samsung	NoteMaster	H1, U1	L105	P	✗
		486C/25	L104	M	✗
	Samsung	M40, NP-Q1, NP-Q30, NX05, NX10, NX15, NX30, P200, P28, P30, P35, P460-44G, P460-44P, P560-54G, P560-54P, Q1B, Q1P, Q1P SSD, Q1P Vista, Q1U-CMXP, Q1U-EL, Q1U-ELXP, Q1U-SSDXP, Q1U-V, Q1U-XP, Q30, Q310-34G, Q310-34P, Q45, R50, R509, R510, R610, R610-64G, R710, X05, X06, X10, X10Plus, X11 (Intel Graphic card), X15, X15Plus, X20, X30, X360-34G, X360-34P, X460-41S, X460-44G, X460-44P	L127 © Freecall now for free tip!		
	Samsung Netbook	NC10	L110	✗	N
	Sens	500, 810	L110	✗	N
		SX30-C160	L127 © Freecall now for free tip!	✗	✗
	700, 800	L130 © Freecall now for free tip!	N	✗	
SensPro	500, 505, 520, 521, 525	L110	✗	N	



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APAG8AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - APME8AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
Sony	Vaio	VGN-FW15G/B, VGN-FW15GB, VGN-FW15GW, VGN-FW16G/W, VGN-FW16GW, VGN-FW17GU/H, VGN-FW17GUH, VGN-FW23G/W, VGN-FW25G/B, VGN-FW26G/B, VGN-FW27GU/H, VGN-FW33G/W, VGN-FW33GW, VGN-FW35G/B, VGN-FW36GJ/B, VGN-FW37, VGN-FW37GY/H, VGN-FW43G/W, VGN-FW43GB, VGN-FW43GW, VGN-FW45GJ/B, VGN-FW45GJB, VGN-FW46GJ/B, VGN-FW46GJB, VGN-FW47GY/H, VGN-FW47GYH, VGN-FW53GF/W, VGN-FW55GF/B, VGN-FW56GF/B, VGN-FW57GH/H, VGN-FZ17G, VGN-FZ25G, VGN-FZ27G, VGN-FZ28G, VGN-FZ323G, VGN-FZ32G, VGN-FZ35G, VGN-FZ35GN, VGN-FZ37G, VGN-FZ38GU, VGN-FZ55GN, VGN-N110G/W, VGN-N11H/W, VGN-N11M/W, VGN-N11S/W, VGN-N130G/W, VGN-N130P/B, VGN-N150G/W, VGN-N150P/B, VGN-N160G/W, VGN-N170G/T, VGN-N170G/W, VGN-N19EP/B, VGN-N19VP/B, VGN-N21E/W, VGN-N21M/W, VGN-N21S/W, VGN-N220E/B, VGN-N220E/W, VGN-N230E/B, VGN-N230E/T, VGN-N230E/W, VGN-N230N/B, VGN-N250E/W, VGN-N250N/B, VGN-N270E/T, VGN-N270E/W, VGN-N27GH, VGN-N29V/B, VGN-N29V/B, VGN-N320E/B, VGN-N320E/W, VGN-N350E/B, VGN-N350E/T, VGN-N350E/W, VGN-N37GHB, VGN-NR27G, VGN-NR37G/S, VGN-NR37GS, VGN-NS15G/S, VGN-NS25G/S, VGN-NW15G/T, VGN-NW15GS, VGN-NW15GT, VGN-NW15GW, VGN-NW17GJ/S, VGN-NW17GJS, VGN-NW23GF/P, VGN-NW25GF/P, VGN-NW29GF/B, VGN-S380, VGN-S380B, VGN-S38GP, VGN-S38GP/B, VGN-S38LP/B, VGN-S38SP, VGN-S3HP, VGN-S3VP, VGN-S3XP, VGN-S430P/S, VGN-S45, VGN-S45SP, VGN-S46, VGN-S460, VGN-S460/B, VGN-S460P/B, VGN-S46GP/S, VGN-S470P/S, VGN-S470P/SKIT, VGN-S470P/SKIT7, VGN-S47SP, VGN-S48, VGN-S480, VGN-S480B, VGN-S48GP/B, VGN-S49, VGN-S4HP, VGN-S4HP/B, VGN-S4HRP/B, VGN-S4M/S, VGN-S4VP/B, VGN-S4XP, VGN-S4XRP/B, VGN-S55, VGN-S550P/S, VGN-S55SP/S, VGN-S56, VGN-S560P/B, VGN-S56GP/S, VGN-S570P/S, VGN-S57SP/B, VGN-S58, VGN-S580, VGN-S58GP/B, VGN-S59, VGN-S5HP, VGN-S5M/S, VGN-S5VP, VGN-S5XP/B, VGN-S660/B, VGN-S67GP/S, VGN-S67TP, VGN-SR16GN/B, VGN-SR16GNB, VGN-SR16GNP, VGN-SR16GNS, VGN-SR16NB, VGN-SR26GN/B, VGN-SR36GN/B, VGN-SR46GD/B, VGN-SR46GDB, VGN-SR46GDP, VGN-SR53GF/W, VGN-SR56GG/B, VGN-SZ110/B, VGN-SZ120P, VGN-SZ120P/B, VGN-SZ140, VGN-SZ140PC, VGN-SZ140PD, VGN-SZ160P/C, VGN-SZ17G, VGN-SZ210P/B, VGN-SZ220/B, VGN-SZ230P/B, VGN-SZ23TP/B, VGN-SZ240, VGN-SZ250P/C, VGN-SZ260P, VGN-SZ26TP/C, VGN-SZ270P/C, VGN-SZ280P/C, VGN-SZ281P/X, VGN-SZ28TP/C, VGN-SZ2VP/X, VGN-SZ320P/B, VGN-SZ330P/B, VGN-SZ340, VGN-SZ360P/C, VGN-SZ370P/C, VGN-SZ381P/X, VGN-SZ38GP, VGN-SZ390, VGN-SZ390PW1, VGN-SZ3HP/B, VGN-SZ3VP/X, VGN-SZ3WVP/X, VGN-SZ3XP/C, VGN-SZ3XWP/C, VGN-SZ430N/B, VGN-SZ433NB, VGN-SZ43GN, VGN-SZ440, VGN-SZ44GN, VGN-SZ450N/C, VGN-SZ453NB, VGN-SZ460N/C, VGN-SZ470N/C, VGN-SZ480, VGN-SZ483NC, VGN-SZ48GN, VGN-SZ491N/X, VGN-SZ4MN/B, VGN-SZ4VN/X, VGN-SZ4VWN/X, VGN-SZ4XWN/C, VGN-SZ55GNB, VGN-SZ5MNB, VGN-SZ75GN/B, VGN-SZ75GNB, VGN-SZ79GNC, VGN-SZ9GN/C, VGN-TX56GN, VGN-Z16GN/B, VGN-Z16GNB, VGN-Z17GN/B, VGN-Z17GNB, VGN-Z26GN/B, VGN-Z27GN/X, VGN-Z36GD/J, VGN-Z37GD/X, VGN-Z46GD/U, VGN-Z46GDB, VGN-Z46GDU, VGN-Z47GD/X, VGN-Z47GDX, VGN-Z48GD/X, VGN-Z48GDX, VGN-Z56GGE, VGN-Z57GGX, VPC-CW15FG/W, VPC-CW1AGG/B, VPC-EB13FGBI, VPC-EB16FGB, VPC-EB17FGB, VPC-EB1AGGBI, VPC-F115FG/B, VPC-S113FG/B, VPC-S117GG/B, VPC-Y115FG/S, X18, X29, X9, XE17, XE7, XG18, XG19, XG28, XG28K, XG29, XG29K, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK	L110	✘	N
		B55T, C1MHP, C1MT, C1MT1, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, PCG-C1MAH, PCG-C1MEL, PCG-C1MTL, PCG-SR19GKRT, PCG-SR19GT, PCG-SRX55H, PCG-SRX55L, PCG-SRX55TH, PCG-SRX55TL, PCG-SRX87, PCG-TR1, PCG-TR1L, PCG-TR1MP, PCG-TR1S, PCG-TR2, PCG-TR2L, PCG-TR2MP, PCG-TR2S, PCG-TR3, PCG-TR3AP3, PCG-TR3S, PCG-TR5AP, PCG-TR5L, PCG-TR5MP, PCG-V505AK, PCG-V505ECP14, PCG-V505GL, PCG-V505GP, PCG-V505GSP, PCG-V505L, PCG-V505MLP, PCG-V505MNP, PCG-V505MNSP, PCG-V505MP, PCG-V505MSP, PCG-V505MZL, PCG-V505P, PCG-V505SP, PCG-Z1GP, PCG-Z1LP, PCG-Z1MP, PCG-Z1RGP, PCG-Z1RLP, PCG-Z1VGP, PCG-Z1VJP, PCG-Z1VLP, PCG-Z1VZLP, PCG-Z1XGP, PCG-Z1XJP, PCG-Z1XLP, PCG-Z1XMP, PCG-Z1XSP, S150, S150P, S18GP, S26TP, S28TP, S36GP, S36TP, SR1, SR11K, SR17, SR17K, SR19G, SR1K, SR21, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, T17TP, T26SP, T37GP, T37SP, TR1, TR1A, TR1AP, TR2, TR2A, TR2AP1, TR2AP3, TR3, TR3A, TR3AP1, TR3AP2, TR5GP, V505A, V505AC, V505AX, V505AXP, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P2, V505DC1P7, V505DC1PC, V505DC1PF, V505DC21, V505DC2P1, V505DX, V505DXP, V505EC, V505EC29, V505ECP1, V505ECP29, V505ECP8, V505EX, V505EXP, V505GP, V505MP, V505P, VGN-B100B, VGN-B100B01, VGN-B100B02, VGN-B100B03, VGN-B100B04, VGN-B100B07, VGN-B100B08, VGN-B100B09, VGN-B100B28, VGN-B100GP, VGN-B1VP, VGN-B1XP, VGN-B3VP, VGN-B3XP, VGN-B55C, VGN-B55G, VGN-B55L, VGN-B55S, VGN-B66GP, VGN-B66SP, VGN-B77GP, VGN-B77SP, VGN-B88C, VGN-B88GP, VGN-B88L, VGN-B99C, VGN-B99GP, VGN-G11VN/T, VGN-G11XN/B, VGN-S16GP, VGN-S16LP, VGN-S16SP, VGN-S170, VGN-S170P6, VGN-S18GP, VGN-S18LP, VGN-S18SP, VGN-S1HP, VGN-S1VP, VGN-S1XP, VGN-S25C, VGN-S260, VGN-S260P, VGN-S26C, VGN-S26GP, VGN-S26LP, VGN-S26SP, VGN-S270, VGN-S270B, VGN-S270B13, VGN-S270P, VGN-S27C, VGN-S28C/P, VGN-S28GP, VGN-S28LP, VGN-S28SP, VGN-S2HP, VGN-S2HRP, VGN-S2VP, VGN-S2XP, VGN-S2XRP, VGN-S360, VGN-S360P, VGN-S36C/B, VGN-S36C/S, VGN-S36GP/S, VGN-S36LP/S, VGN-S36SP, VGN-S38CP/B, VGN-T140P/L, VGN-T140P/LKIT1, VGN-T140P/LKIT2, VGN-T150/L, VGN-T150/LKIT2, VGN-T150P/L, VGN-T150P/LKIT1, VGN-T150P/LKIT2, VGN-T150P/T, VGN-T150P/L, VGN-T160P/L, VGN-T160P/LKIT1, VGN-T160P/LKIT2, VGN-T16GP/S, VGN-T16LP, VGN-T16RLPS, VGN-T16SP, VGN-T170P/L, VGN-T17C/S, VGN-T17GP, VGN-T17GP/S, VGN-T17GP/T, VGN-T17LP, VGN-T1XP/L, VGN-T1XP/T, VGN-T240P/L, VGN-T250/L, VGN-T250P/L, VGN-T250P/S, VGN-T260P/L, VGN-T26C/L, VGN-T26C/T, VGN-T270P/L, VGN-T27C/L, VGN-T27GP, VGN-T27GP/L, VGN-T27GP/S, VGN-T27LP/L, VGN-T27LP/S, VGN-T27TP, VGN-T2XP/L, VGN-T2XP/S, VGN-T340P/L, VGN-T350/L, VGN-T350P/L, VGN-T350P/S, VGN-T350P/T, VGN-T360P/L, VGN-T370P/L, VGN-T37C/L, VGN-TT15GN/B, VGN-TT17GN/X, VGN-TT17GNX, VGN-TT27GD/X,	L130 © Freecall now for free tip!	N	✘



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APA68AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - APA69AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
Sony	Vaio	VGN-TT27GDX, VGN-TT35GNW, VGN-TT35GNB, VGN-TT35GNW, VGN-TT46GG/B, VGN-TT47GG/N, VGN-TT47GG/X, VGN-TX15C, VGN-TX16C, VGN-TX16GP/W, VGN-TX16SP/W, VGN-TX17C, VGN-TX17GP/B, VGN-TX17GP/W, VGN-TX17TP, VGN-TX1HP/W, VGN-TX1XP/B, VGN-TX1XP/L, VGN-TX27GP/B, VGN-TX27GP/T, VGN-TX27GPB, VGN-TX27GPT, VGN-TX27GPW, VGN-TX27TP, VGN-TX2HP/W, VGN-TX2XP/B, VGN-TX36GP/W, VGN-TX37, VGN-TX37GP/B, VGN-TX37GP/T, VGN-TX37GP/W, VGN-TX3HP/W, VGN-TX3XP/B, VGN-TX3XP/L, VGN-TX57GN, VGN-TX5MNN/W, VGN-TX5VN/L, VGN-TX5XN/B, VGN-TX610P/B, VGN-TX630P/B, VGN-TX650P/B, VGN-TX651P/B, VGN-TX670P/B, VGN-TX670P/W, VGN-TX690P/LKIT1, VGN-TX750P/B, VGN-TX770P/B, VGN-TX770P/T, VGN-TX770P/W, VGN-TX790P/L, VGN-TX850P/B, VGN-TXN15P/B, VGN-TXN15P/W, VGN-TXN17P/B, VGN-TXN17P/T, VGN-TXN19P/L, VGN-TXN25N/B, VGN-TXN25N/W, VGN-TXN27N/B, VGN-TXN27N/T, VGN-TXN27N/W, VGN-TXN29N/L, VGN-TZ26GN/W, VGN-TZ27GN/R, VGN-TZ27GNB, VGN-TZ27GNR, VGN-TZ28GN/X, VGN-TZ28GNX, VGN-TZ36GN, VGN-TZ36GN/W, VGN-TZ37GN/B, VGN-TZ37GNB, VGN-TZ37GNN, VGN-TZ37GNP, VGN-TZ37GNR, VGN-TZ38GN/X, VGN-TZ38GNX, VGN-U750P, VGN-U8G, VGN-UX17GP, VGN-UX180P, VGN-UX180PKIT1, VGN-UX1XN, VGN-UX27GN, VGN-UX280P, VGN-UX380N, VGN-UX390N, VGN-UX57GN/L, VGN-UX57GNL, VGN-X505VP, VGN-Y18C, VGN-Y18GP, VX71P, X505, X505ZPKIT, X505ZPKIT2, Z1, Z1A, Z1A1, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP1KITB, Z1RAP2, Z1RAP3, Z1SP, Z1VA, Z1VAP1, Z1VAP1KITB, Z1VAP2, Z1VAP2KITB, Z1WA, Z1WAMP1, Z1WAMP2, Z1WAMP3, Z1WAP, Z1XGP, Z1ZAP1, Z505AX, Z505AXP	L130 © Freecall now for free tip!	N	✗
	Vaio Netbook	VPC-W115XG/P, VPC-W126AG/P, VPC-W213AG/P, VPC-W215AG/L, VPC-W21EAG/WI	L110	✗	N
Toshiba	Libretto	U100 (PLU10A-00500W), U100 (PLU10A-00900W)	L104	M	✗
	Portege	3480CT (PP348E-6PU83), A600 (PPA60A-01H00G), A600 (PPA60A-03800G), A600 (PPA61A-00H005), A600 (PPA61A-00J005), M400 (PPM40A-00F00G), M400 (PPM40A-08M00G), M400 (PPM40A-1HD03D), M400 (PPM40A-1HE03D), M400 (PPM40A-3JS03Y), M400 (PPM40A-3JW03D), M405 (PPM40A-3NY03Y), M500 (PPM51A-01600D), M500 (PPM51A-01P00L), M700 (PPM70A-00W01G), M700 (PPM70A-01Q01G), M700 (PPM70A-03P01G), M700 (PPM70A-0G301G), M700 (PPM70A-0Q201G), M750 (PPM75A-007010G), M750 (PPM75A-01G010), M750 (PPM75A-01Q010), M750 (PPM75A-09U010), M750 (PPM75A-0JW010), R200 (PPR21A-00W01E), R400 (PPR40A-00H00L), R400 (PPR40A-01000L), R500 (PPR50A-00V01X), R500 (PPR50A-00V05C), R500 (PPR50A-02T01X), R500 (PPR50A-04N05C), R500 (PPR50A-04P05C), R500 (PPR50A-07Q05C), R500 (PPR50A-07R05C), R500 (PPR50A-07S05C), R500 (PPR50A-SP101X), R500 (PPR50A-SP105C), R500 (PPR50A-SSD3G), R600 (PPR61A-00300R), R600 (PPR61A-00400R), R600 (PPR61A-01L00R), R600 (PPR61A-02200R), R600 (PPR61A-022040), R600 (PPR61A-02900R), R600 (PPR61A-029040), R600 (PPR61A-02X00R), R600 (PPR61A-02X040)	L104	M	✗
		M600 (PPM60A-035011), M600 (PPM60A-05F01D), M600 (PPM60A-05R011), M600 (PPM60A-06T01D), M600 (PPM60A-06W01D), M600 (PPM60A-07T01D), M600 (PPM60A-09D01D), M800 (PPM80A-01900P), M800 (PPM80A-03H009), M800 (PPM81A-01U01J), M800 (PPM81A-02201J), M800 (PPM81A-04901J), M800 (PPM81A-05701S), M800 (PPM81A-05W01J), M800 (PPM81A-06L01J), M800 (PPM81A-08S01S), M800 (PPM81A-0E101J), M800 (PPM81A-0E201J)	L106	✗	P
	Quosmio	F60 (PQF65A-00Y002)	L106	✗	P
	Satellite	A100 (PSAA9A-046004), A100 (PSAARA-054007), A100 (PSAARA-055007), A100 (PSAARA-05601P), A100 (PSAARA-057007), A100 (PSAARA-058007), A100 (PSAARA-05R007), P100 (PSPA3A-05S00P)	L104	✗	✗
		1800 (PS181X-00XXX), 1800 (PS181X-AAAAX), A100 (PSAA8A-19Y03Q), A100 (PSAA8A-1HQ03R), A100 (PSAA9A-118038), A100 (PSAANA-04E005), M100 (PSMAAA-01M006), M100 (PSMAAA-020006), M100 (PSMAAA-026007), M110 (PSMB0A-01J00D), M110 (PSMB0A-01L00D), M40 (PSM40A-037009), M40 (PSM40A-038009), M40 (PSM40A-03K009), M40 (PSM40A-06X008), M40 (PSM40A-08L009), M40 (PSM40A-0TX008)	L104	M	✗
	1710/1730 (PS170A-0002C), 1730/1750 (PS173A-21KK3), 3000 (PS302A-018XK), A200 (PSAF0A-02L01C), A200 (PSAF0A-03M019), A200 (PSAF0A-04X019), A200 (PSAF0A-04Y019), A200 (PSAF0A-0CQ01C), A200 (PSAF0A-0EV019), A200 (PSAF0A-0YK01C), A200 (PSAF0A-02C01N), A200 (PSAFCA-01400J), A200 (PSAFCA-01600K), A200 (PSAFCA-01C00J), A200 (PSAFCA-01H00J), A200 (PSAFCA-01K00J), A210 (PSAFGA-05C019), A300 (PSAG8A-07V011), A300 (PSAG8A-08D011), A300 (PSAGCA-09U01N), A300 (PSAGCA-0C301N), A300 (PSAGCA-0G601Q), A300 (PSAGDA-01C00R), A300 (PSAGDA-01R014), A300D (PSAH8A-01K00H), A350 (PSAL6A-05D016), A500 (PSAM3A-03P00E), A500 (PSAM3A-03Q00E), A500 (PSAM3A-04000E), A500 (PSAM3A-04100E), A500 (PSAM3A-04200E), A500 (PSAR3A-01K002), A500 (PSAR3A-026002), A500 (PSAR9A-02J001), L300 (PSLB0A-02L022), L300 (PSLB0A-02M027), L300 (PSLB0A-08C022), L300 (PSLB0A-08D022), L300 (PSLB0A-08E022), L300 (PSLB0A-08H022), L300 (PSLB8A-01F004), L300 (PSLB8A-047004), L300 (PSLB8A-04R004), L300 (PSLB8A-04S004), L300 (PSLB8A-058004), L300 (PSLB8A-059004), L300 (PSLB8A-06X004), L300 (PSLB8A-07U004), L300 (PSLB8A-0D3004), L300 (PSLB8A-0D4004), L300 (PSLB8A-0D5004), L300 (PSLB8A-0FM004), L300 (PSLB8A-0KW004), L300 (PSLB8A-0SN004), L300 (PSLB8A-0VK004), L300 (PSLB8A-0WC004), L300 (PSLB8A-0WD004), L300D (PSLC8A-02000Y), L300D (PSLC8A-02200Y), L300D (PSLC8A-02T00Y), L300D (PSLC8A-02U00Y), L300D (PSLC8A-03U00Y), L300D (PSLC8A-03V00Y), L500 (PSLJ0A-01E013), L500 (PSLJ0A-01F013), L500 (PSLJ3A-01R015), L500 (PSLJ3A-01U015), L500 (PSLJ3A-01V015), L500 (PSLJ3A-024015), L500 (PSLJ3A-02501Y), L500 (PSLS0A-016002), L500 (PSLS0A-01W002), L500 (PSLS0A-034002), L500 (PSLS0A-087002), L500 (PSLS0A-049002), L500 (PSLS6A-00X013), L500 (PSLS9A-025012), L500 (PSLS9A-02C012), L500D (PSLK0A-00R009), L500D (PSLK0A-00U009), L500D (PSLK0A-00W009), L500D (PSLT0A-00V001), L510 (PSLF2A-01S00R), L510 (PSLF2A-01T00R), L510 (PSLF2A-01U00R), L510 (PSLFEA-01500C), L550 (PSLN8A-00Y008), L550 (PSLW8A-01101F), L550 (PSLWSA-01000Q), M200 (PSMC0A-01X00N), M200 (PSMC0A-02G00M), M200 (PSMC3A-04P008), M200 (PSMC3A-06N008), M200 (PSMC6A-03Q00S), M300 (PSMD0A-02700E), M300 (PSMD0A-04S00E), M300 (PSMD4A-023008),	L106	✗	P	



Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage automatically. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APAG8AU	75W AC APA02AU	90W AC	90W AC
90W AC/DC - APN89AU			APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
Toshiba	Satellite	M300 (PSMD8A-03H00G), M300 (PSMDCA-01800C), M300 (PSMDCA-01900C), M300 (PSMDCA-01T00C), M300 (PSMDCA-03600R), M300 (PSMDCA-03700R), M300 (PSMDCA-03800R), M300 (PSMDCA-03J00R), M300 (PSMDCA-06F00R), M300 (PSMDCA-06G00R), M300 (PSMDCA-06J00S), M300 (PSMDCA-06K00R), M500 (PSMK-CA-009007), P200 (PSPBGA-01W015), P200 (PSPBGA-01X015), P500 (PSPE8A-01R002), P500 (PSPE8A-024008), P500 (PSPG8A-01U004), P500 (PSPG8A-020004), T110 (PST1AA-00D007), T110D (PST1LA-00C008), T130 (PST3AA-02F006), T130 (PST3AA-02M02M), T130 (PST3AA-03F02M), U300 (PSU30A-02Y01U), U300 (PSU30A-05302P), U300 (PSU30A-0DJ02P), U400 (PSU40A-01M001), U400 (PSU40A-01S001), U400 (PSU44A-00H00C), U400 (PSU44A-00J00C), U400 (PSU44A-02C01D), U400 (PSU44A-03S01D), U400 (PSU44A-08W01D), U500 (PSU5EA-00X012), U500 (PSU82A-01W00M), U500 (PSU8CA-01D014), U500 (PSU9BA-01C002), U500 (PSU9MA-00K013)	L106	✗	P
		P100 (PSPA4A-005002), P100 (PSPA4A-016002), P100 (PSPAEA-00G00D), P100 (PSPAEA-00J00D)	L104	✗	✗
		A120 (PSAC0A-00D002), A120 (PSAC1A-00K005), A120 (PSAC1A-045005), A120 (PSAC1A-073004), A120 (PSAC1A-0QP01X), A120 (PSAC1A-0QV03J), A120 (PSAC1A-0R903H), A120 (PSAC1A-0VW03H), A120 (PSAC1A-0VX03J), S200 (PSSA1A-00V008), S200 (PSSA1A-0G9007), S300 (PSSB0A-06C00K), S300 (PSSB0A-06V00K)	L104	M	✗
	Satellite Pro	A200 (PSAF1A-001001), A200 (PSAF1A-003002), A200 (PSAF4A-001001), A200 (PSAF4A-003007), A200 (PSAF4A-008009), A200 (PSAF4A-009009), A200 (PSAF4A-00H007), A200 (PSAF4A-00J009), A200 (PSAF4A-00K009), A200 (PSAF4A-00S009), A200 (PSAF7A-003001), A210 (PSAFHA-00W008), A210 (PSAFHA-00W00L), A210 (PSAFHA-00X008), A210 (PSAFHA-00X00L), A210 (PSAFHA-01P00L), A300 (PSAG1A-003002), A300 (PSAG8A-03C011), A300 (PSAG8A-05P02D), A300 (PSAGDA-01Y00R), A300 (PSAGDA-03700R), A300 (PSAGDA-03D00R), L30 (PSL30A-00100E), L300 (PSLB1A-01L019), L300 (PSLB1A-01L019), L300 (PSLB1A-01N008), L300 (PSLB1A-02C01E), L300 (PSLB1A-02D008), L300 (PSLB1A-02R01E), L300 (PSLB1A-02S008), L300 (PSLB9A-00L002), L300 (PSLB9A-013001), L300 (PSLB9A-01G002), L300 (PSLB9A-02H002), L300 (PSLB9A-02K002), L300 (PSLB9A-02L001), L300 (PSLB9A-03T002), L300 (PSLB9A-058001), L300 (PSLB9A-05U002), L300 (PSLB9A-05W002), L300 (PSLB9A-064002), L300 (PSLB9A-067001), L300 (PSLB9A-06D002), L500 (PSLS1A-007002), L500 (PSLS1A-01200K), L500 (PSLS1A-022002), L500 (PSLS1A-02T00K), L500 (PSLS4A-00500L), L500 (PSLS4A-01100L), L500 (PSLS4A-01200L), L500 (PSLS4A-01F00L), L500 (PSLS4A-01G00L), L500 (PSLSAA-00K00U), L500 (PSLSAA-00L00U), L510 (PSLGXA-002002), L510 (PSLQ1A-004005), L510 (PSLS3A-020002), L510 (PSLT0A-00D001), L550 (PSLW9A-00X00N), L550 (PSLW9A-00Y00N), L550 (PSLWTA-00J00G), L550 (PSLWTA-00K00G), M200 (PSMC4A-00C001), M200 (PSMC4A-01N00C), M300 (PSMD1A-005004), M300 (PSMD9A-003002), M300 (PSMD9A-004002), M300 (PSMD9A-007002), M300 (PSMD9A-009002), P300 (PSPCDA-01N00D), P300 (PSPCDA-01P00D), P300 (PSPCDA-03P00D), T110 (PST-1BA-009007), T130 (PST3BA-00M00U), T130 (PST3BA-00N00U), U500 (PSU83A-00N00D), U500 (PSU9CA-00D003), U500 (PSU9NA-00600N)	L106	✗	P
Toshiba	Tecra	A6 (PTA63A-002002), A7 (PTA71A-012003), A7 (PTA71A-0DU003), A7 (PTA71A-0DW003), A7 (PTA71A-1EU003), A8 (PTA83A-0HV041)	L104	✗	✗
		A10 (PTSB0A-002001), A10 (PTSB0A-006001), A10 (PTSB0A-00E001), A10 (PTSB0A-020001), A10 (PTSB0A-02D001), A10 (PTSB0A-03E001), A10 (PTSB0A-03G001), A10 (PTSB0A-04L001), A10 (PTSB0A-04X023), A10 (PTSB0A-04Y023), A10 (PTSB0A-059023), A10 (PTSB0A-05C023), A11 (PTSE1A-00K005), A11 (PTSE1A-00L005), A8 (PTA83A-0HU041), A8 (PTA83A-0HV041), A8 (PTA83A-042012), A8 (PTA83A-04F012), A8 (PTA83A-04G012), A8 (PTA83A-054012), A8 (PTA83A-056012), A9 (PTS52A-00U00F), A9 (PTS52A-00V00F), A9 (PTS52A-023017), A9 (PTS52A-0CT017), A9 (PTS52A-0CU03F), A9 (PTS52A-0CV03F), A9 (PTS52A-0CW03F), A9 (PTS52A-0EV017), A9 (PTS52A-0EW03F), A9 (PTS52A-0EX03F), A9 (PTS52A-0EY03F), A9 (PTS52A-0GF03F), M10 (PTMB0A-00M001), M10 (PTMB0A-04S001), M10 (PTMB0A-05602H), M10 (PTMB3A-00L004), M10 (PTMB3A-00M004), M10 (PTMB3A-00N004), M10 (PTMB3A-01X001), M10 (PTMB3A-04L001), M10 (PTMB3A-05C004), M10 (PTMB3A-05E004), M10 (PTMB3A-0D3004), M10 (PTMB3A-0DJ004), M10 (PTMB3A-0G0004), M10 (PTMB3A-0HK004), M10 (PTMB3A-0KH06C), M10 (PTMB3A-0N606C), M10 (PTMB3A-0NP06C), M5 (PTM51A-0EG007), M5 (PTM51A-0EJ007), M5 (PTM51A-0RL05P), M5 (PTM51A-0RM05P), M5 (PTM51A-0RW05P), M5 (PTM51A-1FQ07P), M7 (PTM71A-01101H), M9 (PTM90A-01V00K), M9 (PTM90A-08P03H), M9 (PTM90A-0C603H), M9 (PTM90A-0CL03H), M9 (PTM91A-035002), M9 (PTM91A-036002), M9 (PTM91A-037002), M9 (PTM91A-05504L), M9 (PTM91A-0E104L), M9 (PTM91A-0EY04L), M9 (PTM91A-0MF04L), M9 (PTM91A-0MG04L), M9 (PTM91A-0T304L), M9 (PTM91A-0U204L), M9 (PTM91A-0U204L), P (PTS40A-02100V), P (PTS40A-02800V), P10 (PTSB3A-001001), P10 (PTSB3A-00S001), P10 (PTSB3A-05Q001), P10 (PTSB3A-05R001), P10 (PTSB3A-07U016), P10 (PTSB3A-0GE001), P10 (PTSB3A-0GF001), P10 (PTSB3A-0HE001), P10 (PTSB3A-0UV048), P10 (PTSB3A-0VD001), P10 (PTSB3A-0VR048), P11 (PTSE3A-00T00K), P11 (PTSE3A-00U00K), P11 (PTSE3A-00V00K), P5 (PTS53A-007006), P5 (PTS53A-009006), P5 (PTS53A-01G006), P5 (PTS53A-02F01D), P5 (PTS53A-05H03X), P5 (PTS53A-05Y01D), P5 (PTS53A-05Y03X), P5 (PTS53A-06003X), P5 (PTS53A-0FR03X), P5 (PTS53A-0FS03X), P5 (PTS53A-0FT03X), R10 (PTRB3A-001002), R10 (PTRB3A-00T002), R10 (PTRB3A-00U002), S3 (PTS30A-094008), S3 (PTS30A-0CG008)	L104	M	✗
	Toshiba Netbook	NB100 (PLL10A-00K02H), NB100 (PLL10A-01C02H), NB100 (PLL10A-01E02H), NB200 (PLL20A-002001), NB200 (PLL20A-00P001), NB200 (PLL20A-00Q001), NB200 (PLL23A-00501G), NB200 (PLL23A-00C01G), NB200 (PLL23A-00D01G), NB200 (PLL25A-009002), NB200 (PLL25A-00C002), NB200 (PLL25A-00D002), NB200 (PLL25A-00K002), NB200 (PLL28A-007012), NB200 (PLL28A-00E012), NB300 (PLL3EA-006007), NB300 (PLL3EA-00F007), NB305 (PLL3AA-00F009), NB305 (PLL3AA-00T009), NB305 (PLL3AA-01E009)	L106	✗	P
WinBook	WinBook	J1, N, Si, Si2, X1, X2, X4, XL, XLI, XP, Z	L106	✗	P