



Targus

To determine the correct connector to use for your laptop:

1. Find the brand of laptop in the alphabetized list.
2. Find the model name and number of your laptop in that section.
3. Match the connector/tip number you find in the column next to your model number with the number molded into the connector/tip.
4. If you cannot find your model number on this list, please go to www.targus.com/us/powerstore.asp to find the most up-to-date list of compatible devices or call us at **877.482.7487** for assistance.

Laptop Connector Compatibility Chart

TIP	ACER	TIP	COMPAQ	TIP	COMPAQ (cont.)	TIP	GATEWAY (cont.)
201	Aspire: 5612WLMi, 3025WLMi, 5023WLMi, 5100-3372, 5610 series, 5633WLMi, 7720, 9502WSMi, 9503EWSM, 9504EWSM, 9504WSMi TravelMate: 2100, 2420, 2430, 2490, 2600, 2700, 3240, 3280, 3290, 3900, 4200 series, 4210, 4220, 4230, 4230-6499, 4230-6704, 4260, 4270, 4280, 4401LMi, 4672WLMi, 5110, 5610, 5620, 6410, 6410-6189, 6410-6248, 6460, 6460-6263, 6460-6752, 6479, 6500, 8200, 8202WXM, 8204WLMi, 8210 Aspire: 5570z, 5580-6432 AcerNote: 367D, 367T, 390 Anywhere: 1100LX, 1120LX Extensa: 366D, 367D, 367T, 368D, 391C, 391T, 392C, 392T, 393, 393C, 393T, 394T, 395T, 900, 900CDT, 900T, Ess3-391T Extensa: 515 TravelMate: 512DX, 512T Aspire: 1200, 1680, 1690, 2001LCi, 2002LCi, 2002LMi, 2003LMi, 2012WLCi, 2012WLMi, 2025WLMi, 3000, 3002LC, 3002LMi, 3003WLMi, 3022WLMi, 3050-1047, 3050-1594, 3618AWLCi, 3634WLMi, 3680-2022, 3680-2633, 3690-2710, 5002WLMi, 5024, 5050-5278, 5100-3357, 5100-3577, 5100-3583, 5100-3825, 5100-3959, 5100-5328, 5100-5540, 5100-5840, 5100-5873, 5110-5447, 5570-2609, 5570-2758, 5570-2792, 5570-2935, 5570-4421, 5680-6509, 9410-4923 Extensa: 2300 Ferrari: 5005WLMi-FR Tablet: TMC104TCi, TMC110TCi, TMC110Ti TravelMate: 2200, 222X, 223X, 225X, 225XC, 225XV-PRO, 2300, 2301LC, 2301LCi, 2301WLCi, 2301XC, 2303LC, 2303LCi, 2304LCi, 2304WLCi, 230X, 230XC, 230XV, 230XV-PRO, 2310, 233LC, 233X, 233XV, 233XVi, 234LCi, 2350, 2400, 2450, 2460, 2470, 2480, 2480-2153, 2480-2551, 2480-2705, 2480-2779, 261XC, 261XV, 272LC, 272XV, 273LC, 273XV, 281XC, 281XV, 283LC, 283LCi, 283XV, 283XVi, 290, 292, 3000, 3000WWTMi, 3004WTMi, 3010, 3020, 3030, 3040, 3200, 3210, 3220, 3230, 3250, 3260, 3270, 3270-6569, 3300, 350TE-N, 351TE-N, 351TEV, 351TEV-D, 351TEV-N, 353TEV, 354TEV, 380, 4000, 4000LCi, 4000WLCi, 4001LCi, 4001WLCi, 4001WLMi, 4002WLMi, 4010, 4020, 4050, 4060, 4070, 4080, 4100, 4150, 4501WLMi, 4502WLMi, 4600, 4650, 6000, 6003LMi, 6020, 6030, 6050, 6050NT, 610TXVi, 610TXVi-Me, 611TXCi, 611TXCi-d, 611TXV, 612TXCi, 612TXV, 613TXV, 614TXCi, 630XCi, 630XV, 632XCi, 633LCi, 634XCi, 636LCi, 661LCi, 662LMi, 730TXV, 732TLV, 732TXV, 734TL, 734TXV, 735TLV, 736TL, 736TLV, 737TLV, 738TLV, 739GLV, 739TLV, 740LVF, 741LVF, 744LCF, 8000, 8002LCi, 8003LMi, 8006LMi, 800LCi, 800XCi, 802LCi, 803LCi, 804LMi, 8100, 8100A, 8103WLMi, 8104WLMi, C110, C200, C210, C301XCi, C301XCi-G, C301XCi-G-SP, C302XCi, C302XMi, C303XMi, C310, TM279, TM360, TM370, TM380, TM520, TM530, TM620, TMC113LCi ASUS A1 series, F7 series, F7000, L1 series, L7 series, L7000, L7000C, L7200, L7300, L8 series, M1 series, M5, M5N, M8 series, S1 series, S200, S200N, S300N, S5, S5N, S8 series, T9 series, M5200N, S5200N, GRANDIO F7400	201	NC8230, NW8420, NX8220 Evo: N1000v, N1015v, N1020v Presario: 1501AP, 1501CL, 1502LA, 1503AP, 1504AP, 1505US, 1506AP, 1507AP, 1508AP, 1509AP, 1510AP, 1510CA, 1510TC, 1510US, 1511AP, 1512AP, 1514AP, 1520AP, 1520CA, 1520LA, 1520US, 1522AP, 1522EA, 1522LA, 1523EA, 1525AP, 1525CA, 1525EA, 1525US, 1527EA, 1528AP, 1528CL, 1530SC, 1531AP, 1532AP, 1535AP, 1536AP, 1538AP, 1540AP, 1545AP, 1550AP, 1555AP, 1565AP, 1570AP, 1572AP, 1575AP, 1580AP, 901EA, 902EA, 903EA, 904RSH, 905LA, 905US, 906US, 907EA, 908EA, 909EA, 910AP, 910EA, 910US, 911DE, 912EA, 912RSH, 914EA, 915CA, 915EA, 915US, 916US, 917DE, 917EA, 918RSH, 919EA, 920AP, 920CA, 920EA, 920LA, 920US, 921AP, 922UK, 923AP, 925AP, 925EA, 927AP, 930AP, 935AP, 940AP, 943AP, 945AP, 950AP, 955AP, N1050V, V6305NR NC4000, NC4010, NC4200, NC6000, NC6120, NC6200, NC6220, NC6230, NC8000, NW8000, NX5000, NX6100, NX6110, NX6115, NX6120, NX6125, NX7000, NX7010, NX7200, TC4200, V3000, V3000z, V3016US Armada: 110, E500, E500S, E700, M300, M700, V300 Business Notebook: NX6120, NX9020, NX9030, NX9040 Evo: N110, N150, N200, N400c, N410c, N600c, N610c, N620c, N800c, N800V, N800w Presario: 2200 Series, 2800 Series, 2900 Series, 305, B3800, C300EU, C302NR, C303NR, C304NR, C306US, C307NR, C310EU, C350EA, C350EU, C500EA, C500EU, C501NR, C501T, C502CA, C502EA, C502EU, C502TU, C502US, C503TU, C503WM, C504EA, C504EU, C504TU, C504US, C506CA, C506TU, C507US, C508US, C509NR, C518LA, C540EA, C542EA, C551NR, C551TU, C552CA, C552TU, C552US, C553TU, C554TU, C554US, C555EA, C555EU, C555TU, C556CA, C556TU, C557CL, C557TU, C558TU, C559TU, C560TU, C561TU, C562TU, C563TU, C564TU, C565TU, C566TU, C567TU, C570EA, F502EA, F502EU, F504EA, F545EA, F555US, F557US, DV6000T, M2000 Series, M2100 Series, M2200 Series, M2301NR, M2305NR, M2401XT, V1000 Series, V1100 Series, V2000 Series, V2100, V2110US, V2135US, V2140CA, V2140US, V2205US, V2220US, V2300 Series, V2400 Series, V2500 Series, V2600 Series, V2610CA, V2710CA, V2710US, V3000T, V3010CA, V3010US, V3015CA, V3018US, V3019US, V3020CA, V3020US, V3030CA, V3200 Series, V4000 Series, V4100 Series, V4201TU, V4202TU, V4205EA, V4215EA, V4310NR, V4325CA, V4325US, V4332US, V4435NR, V4440US, V5000 Series, V5100 Series, V5200 Series, V5303NR, V5304US, V5305WM, V5306US, V5307US, V5308US, V5310US, V5315WM, V6000 Series, V6100 Series, V6205NR, V6210CA, V6210US, V6215CA, V6230CA, V6254EA, V6305NR, V6310CA, V6310US, V6320CA, V6325EA, X1000 Series, X1100 Series, X1200 Series, X1300 Series, X1400 Series, ZT3000LA Prosignia: 170, 190 Tablet: TC1000, TC1100 Evo: N115, N160, N180 Presario: 700 Series, 800T, 801, 802, 803, 850, 1010, 1020, 1030, 1060, 1065, 1070, 1075, 1080US, 1200 Series, 12XL Series,	206 (cont.)	1400T, 14XL240, 1600 Series, 16XL, 1700 Series, 17XL260, 1800T, 1800US, 1800XL, 180, 18XL280, 2505EA, 2510EA, 2520EA, 2528EA, 2558EA, 2700 Series, 2810EA, 2820EA, 2528EA, 2558EA Prosignia: 150 2510p, 2710p, 6510b, 6515b, 6710b, 6710s, 6715b, 6715s, 6715sb, 6820s, 6910p, 8510p, 8510w, CN2400, NC4400, NC6140, NC632, NC6400, NC8430, NW8440, NX6310, NX6325, NX7300, NX7400, NX8420, NX9420, TC4400 DELL Inspiron: 1200, 1300, 2200, 3000, 3200, 3500, 7000, B120, B130 Latitude: 110L Inspiron: 1150, 1420, 1501, 1520, 1521, 1720, 1721, 300M, 500M, 510M, 6000, 600M, 630M, 6400, 640M, 700M, 710M, 8500, 8600, 9200, 9300, 9400, E1405, E1505, E1705 Latitude: 131L, ATG, D400, D410, D420, D430, D500, D505, D510, D520, D531, D600, D610, D620, D630, D800, D810, D820, D830, L100, X1, X300 Precision: M20, M60, M65, M70, M2300, M4300 XPS: M140, M1210, M1330 FUJITSU Lifebook: A1010, Amilo L, C1410, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2340, E2010, E4010D, E6624, E6634, E6644, E6654, E6664, E7010, E7110, E8010, E8010D, E8020, E8020D, E8110, E8210, N3510, N3520, N3530, N6110, N6210, N6220, S7010, S7010D, S7110, T4010, T4010D, T4020, T4210 GATEWAY 400SD4, 400VTX, 6040GZ, 3018GZ, 3040GZ, 3520GZ, 3522GZ, 3525GZ, 3545GZ, 3550GH, 3550GZ, 3610GZ, 4012GZ, 4024GZ, 4025GZ, 4026GZ, 4028GZ, 405E, 405X, 450RGH, 450ROG, 450SX4, 4520GZ, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 4542GP, 600YG2, 600YGR, 6010GZ, 6018GH, 6018GZ, 6020GZ, 6021GH, 6021GZ, 6022GZ, 6023GP, 6510GZ, 6518GZ, 6520GZ, 6525GP, 6531GZ, 8510GH, 8510GZ, CX200S, CX200X, CX210S, CX2608, CX2610, CX2618, CX2619, CX2620, CX2720, CX2724, CX2726, CX2728, E-100M, E-100MG, E-100MSB, M210, M250, M250A, M250B, M250ES, M250G, M250GS, M255E, M255ESB, M255G, M275, M280, M280EQS, M285E, M285ESB, M285G, M305CRV, M360, M360A, M360B, M360C, M405, M460, M460A, M460B, M460QS, M465E, M465G, M305, M500, M505, M680, ML3706, MP6954, MP8708, MT3418, MT3705, MT3708, MT6451, MT6452, MT6458, MT6705, MT6707, MT6821, MT6828, MT6830, MT6831, MX3042, MX3044, MX3044h, MX3210, MX3215, MX3228, MX3230, MX3231, MX3414, MX3416, MX3558, MX3560, MX3560h, MX3562, MX3563, MX3563h, MX6025, MX6025h, MX6027, MX6027h, MX6028, MX6030, MX6121, MX6123, MX6124, MX6124h, MX6128, MX6131, MX6214, MX6421, MX6422, MX6425, MX6426, MX6427, MX6431, MX6436, MX6437, MX6439, MX6440, MX6444, MX6445, MX6446, MX6447, MX6448, MX6450, 	206 (cont.)	MX6453, MX6454, MX6455, MX6625, MX6627, MX6627h, MX6635b, MX6638b, MX6641, MX6650, MX6650h, MX6710, MX6912, MX6920, MX6927, MX6930, MX6931, MX8520, MX8525, MX8711, MX8734, NX100X, NX200S, NX200X, NX250X, NX260X, NX270S, NX500S, NX500X, NX500XL, NX510, NX550X, NX550XL, NX560X, NX570QS, NX570S, NX570XL, NX850X, NX850XL, S-7200C, S-7200N, S-7500N, S-7700N Solo: 1100, 1150, 1200, 1400, 1450, 2150, 2300, 2500, 2550, 3100, 3150, 5150, 5300, 5350, 9100, 9150, 9300, 9300VE, 9500, 9550 Solo Pro: 9300-E Tablet: M1200, M1300 HP PAVILION: DV8339US, DV2000T, DV2085, DV6000, DV6002G, DV6001EA, DV6001XX, DV6003EA, DV6004EA, DV6005EA, DV6006EA, DV6007EA, DV6013EA, DV6014EA, DV6015EA, DV6016EA, DV6017EA, DV6018EA, DV6019EA, DV6020EA, DV6021EA, DV6022EA, DV6025EA, DV6040CA, DV6040US, DV6045NR, DV6054EA, DV6057EA, DV6058CL, DV6059EA, DV6060EA, DV6061US, DV6062EA, DV6063EA, DV6065EA, DV6067EA, DV6068EA, DV6087EA, DV6088EA, DV6095EA, DV6097EA, DV6097EA, DV6110US, DV6113TX, DV6116EA, DV6116TX, DV6118EA, DV6120US, DV6121TX, DV6122TX, DV6130EU, DV6110US, DV6142EA, DV6146EA, DV6148EA, DV6149US, DV6150EA, DV6150US, DV6152EA, DV6155EA, DV6156EU, DV6157EA, DV6162EA, DV6174CL, DV6174EA, DV6184EU, DV6205US, DV6258SE, DV6275US, DV6285EU, DV6295EU, DV6331EU, DV6357EA, DV6375US, DV8000, DV8380US, DV8408US, DV9000, DV9000T, DV9000Z, DV9001EA, DV9001XX, DV9003XX, DV9005EA, DV9005US, DV9006EA, DV9007TX, DV9008NR, DV9009NR, DV9010TX, DV9015EA, DV9018TX, DV9022EA, DV9023US, DV9024EA, DV9030EA, DV9040US, DV9042EA, DV9043EA, DV9044EA, DV9047EA, DV9050EA, DV9051EA, DV9053EA, DV9054EA, DV9056EA, DV9057EA, DV9060US, DV9061EA, DV9065EA, DV9074EA, DV9075EU, DV9076EA, DV90879, DV9083EA, DV9088EA, DV9089EA, DV9091EA, DV9092EA, DV9093EU, DV9095EA, DV9096EA, DV9098XX, DV9205US, DV9206EU, DV9210US, DV9212EA, DV9217EA, DV9220US, DV9225US, DV9230US, DV9233EU, DV9235NR, DV9260NR, DV9263EU, DV9267EA, DV9288EA, DV9289EA, DV9292EU, DV9299EA, DV9304, DV9308NR, DV9310CA, DV9310US, DV9330US, DV9335NR, DV9339NR, DV9350EA, DV9398EA 530, DV1710US, DV1506TX, DV1555EU, DV6302EU, L2000, L2005A3, L2005CL, L2005CU, L2005US, L2098XX, L2099XX Business Tablet: TC4200 Pavilion: DV1000 Series, DV1100 Series, DV1200 Series, DV1300 Series, DV1410US, DV1411SE, DV1420US, DV1427US, DV1430US, DV1432US, DV1439CA, DV1440US, DV1510US, DV1519US, DV1520US, DV1530US, DV1540US,
102	ASUS A1 series, F7 series, F7000, L1 series, L7 series, L7000, L7000C, L7200, L7300, L8 series, M1 series, M5, M5N, M8 series, S1 series, S200, S200N, S300N, S5, S5N, S8 series, T9 series, M5200N, S5200N, GRANDIO F7400	206	Evo: N115, N160, N180 Presario: 700 Series, 800T, 801, 802, 803, 850, 1010, 1020, 1030, 1060, 1065, 1070, 1075, 1080US, 1200 Series, 12XL Series,	206	Evo: N115, N160, N180 Presario: 700 Series, 800T, 801, 802, 803, 850, 1010, 1020, 1030, 1060, 1065, 1070, 1075, 1080US, 1200 Series, 12XL Series,	102	Solo Pro: 9300-E Tablet: M1200, M1300 HP PAVILION: DV8339US, DV2000T, DV2085, DV6000, DV6002G, DV6001EA, DV6001XX, DV6003EA, DV6004EA, DV6005EA, DV6006EA, DV6007EA, DV6013EA, DV6014EA, DV6015EA, DV6016EA, DV6017EA, DV6018EA, DV6019EA, DV6020EA, DV6021EA, DV6022EA, DV6025EA, DV6040CA, DV6040US, DV6045NR, DV6054EA, DV6057EA, DV6058CL, DV6059EA, DV6060EA, DV6061US, DV6062EA, DV6063EA, DV6065EA, DV6067EA, DV6068EA, DV6087EA, DV6088EA, DV6095EA, DV6097EA, DV6097EA, DV6110US, DV6113TX, DV6116EA, DV6116TX, DV6118EA, DV6120US, DV6121TX, DV6122TX, DV6130EU, DV6110US, DV6142EA, DV6146EA, DV6148EA, DV6149US, DV6150EA, DV6150US, DV6152EA, DV6155EA, DV6156EU, DV6157EA, DV6162EA, DV6174CL, DV6174EA, DV6184EU, DV6205US, DV6258SE, DV6275US, DV6285EU, DV6295EU, DV6331EU, DV6357EA, DV6375US, DV8000, DV8380US, DV8408US, DV9000, DV9000T, DV9000Z, DV9001EA, DV9001XX, DV9003XX, DV9005EA, DV9005US, DV9006EA, DV9007TX, DV9008NR, DV9009NR, DV9010TX, DV9015EA, DV9018TX, DV9022EA, DV9023US, DV9024EA, DV9030EA, DV9040US, DV9042EA, DV9043EA, DV9044EA, DV9047EA, DV9050EA, DV9051EA, DV9053EA, DV9054EA, DV9056EA, DV9057EA, DV9060US, DV9061EA, DV9065EA, DV9074EA, DV9075EU, DV9076EA, DV90879, DV9083EA, DV9088EA, DV9089EA, DV9091EA, DV9092EA, DV9093EU, DV9095EA, DV9096EA, DV9098XX, DV9205US, DV9206EU, DV9210US, DV9212EA, DV9217EA, DV9220US, DV9225US, DV9230US, DV9233EU, DV9235NR, DV9260NR, DV9263EU, DV9267EA, DV9288EA, DV9289EA, DV9292EU, DV9299EA, DV9304, DV9308NR, DV9310CA, DV9310US, DV9330US, DV9335NR, DV9339NR, DV9350EA, DV9398EA 530, DV1710US, DV1506TX, DV1555EU, DV6302EU, L2000, L2005A3, L2005CL, L2005CU, L2005US, L2098XX, L2099XX Business Tablet: TC4200 Pavilion: DV1000 Series, DV1100 Series, DV1200 Series, DV1300 Series, DV1410US, DV1411SE, DV1420US, DV1427US, DV1430US, DV1432US, DV1439CA, DV1440US, DV1510US, DV1519US, DV1520US, DV1530US, DV1540US,

Laptop Connector Compatibility Chart (continued)

TIP	HP (cont.)	TIP	HP (cont.)	TIP	SONY (cont.)	TIP	SONY (cont.)		
102 (cont.)	DV1550SE, DV1580SE, DV1610US, DV1620US, DV1624NR, DV1629US, DV1648US, DV1650S, DV1656US, DV1658US, DV1659US, DV1660SE, DV1680CA, DV1688US, DV1708NR, DV1738OD, DV2035US, DV2104EA, DV2104EU, DV2110RS, DV2120US, DV2125NR, DV2130US, DV2201CA, DV2205EA, DV2210US, DV2214US, DV2220US, DV2221US, DV2225NR, DV2227EA, DV2310US, DV2315NR, DV2415, DV2615, DV2660, DV4000 Series, DV4100 Series, DV4200 Series, DV4305US, DV4307CA, DV4307CL, DV4308WM, DV4310US, DV4320US, DV4330CA, DV4330US, DV4335US, DV4340US, DV4401RS, DV4405RS, DV4419US, DV4420CA, DV44935WM, DV5000, DV5000T, DV5020US, DV5029US, DV5030US, DV5035NR, DV50400US, DV5100 Series, DV5200 Series, DV6010EA, DV6011EA, DV6023EA, DV6100 Series, DV6200 Series, DV6300 Series, DV6364, DV6449, DV6470, DV6623, DV6626, DV6648, DV6653, DV6662, DV6670, DV8000 Series, DV8110us, DV8125NR, DV8130US, DV8135NR, DV8140US, DV8200, DV8210US, DV8220US, DV8225NR, DV8240US, DV8301NR, DV8305CA, DV8305US, DV8309US, DV8310CA, DV8310US, DV8315NR, TX1000 Series, TX1110US, TX1115NR, TX1120US, TX1205, TX1210, TX1220, TX1305, TX1308, TX1410, ZE2000 Series, ZE2100 Series, ZE2200 Series, ZE2308WM, ZE2309NR, ZE2315US, ZE2401XT, ZE4900 Series, ZT3000 Series, ZT3100 Series, ZT3200 Series, ZT3300 Series	206 (cont.)	XT555, XT565, XT575, XT585, XT595, XU/ZU BTCCO, XU155, XZ133, XZ148, XZ163, XZ168, XZ185, XZ275, XZ295, XZ335, XZ355, ZE1000, ZE1110, ZE1115, ZE1145, ZE1201, ZE1202, ZE1210, ZE1230, ZE1250, ZE1260, ZE4101, ZE4102, ZE4103, ZE4105, ZE4111, ZE4115, ZE4120, ZE4123, ZE4125, ZE4130, ZE4133, ZE4140, ZE4145, ZE4200, ZE4201, ZE4202, ZE4204, ZE4206, ZE4207, ZE4208, ZE4209, ZE4210, ZE421, ZE4214, ZE4218, ZE4219, ZE4220, ZE4221, ZE4222, ZE4224, ZE4228, ZE4229, ZE4230, ZE4231, ZE4232, ZE4234, ZE4236, ZE4239, ZE4240, ZE4241, ZE4251, ZE4258, ZE4261, ZE4268, ZE4271, ZE4274, ZE4278, ZE4281, ZE4282, ZE4284, ZE4288, ZE4292, ZE4294, ZE4298, ZE4301, ZE4305, ZE4307, ZE4308, ZE4310, ZE4311, ZE4312, ZE4313, ZE4314, ZE4315, ZE4315US, ZE4316, ZE4317, ZE4318, ZE4319, ZE20, ZE4321, ZE4323, ZE4325, ZE4325US, ZE4330, ZE4332, ZE4333, ZE4334, ZE4335, ZE4336, ZE4345, ZE4347, ZE4348, ZE434349, ZE4351, ZE4352, ZE4353, ZE4354, ZE4355, ZE4356, ZE4357, ZE4360, ZE4365, ZE4367, ZE4375, ZE4384, ZE4385, ZE4386, ZE5715CA, ZT1000-IB BTCCO, ZT1114, ZT1120, ZT1121, ZT1121S, ZT1122, ZT1122S, ZT1125, ZT1130, ZT1131, ZT1131S, ZT1132, ZT1132S, ZT1135, ZT1141, ZT1142, ZT1145, ZT1150, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1170, ZT1171, ZT1172, ZT1175, ZT1180, ZT1181, ZT1182, ZT1185, ZT1190, ZT1192, ZT1201, ZT1201S, ZT1210, ZT1211, ZT1213, ZT1230, ZT1231S, ZT1233, ZT1235, ZT1243, ZT1250, ZT1260, ZT1261, ZT1270, ZT1271, ZT1290, ZT1331, ZU175, ZU1155, ZU1175	209 (cont.)	FX601, FX602, FX604, FX605, FX701, FX702, FX705, FX770K, FX800, FX801, FX802, FX805, FX880K, FX902P, FX905P, FXA32, FXA33, FXA36, FXA63, GRS100, GRS150, GRS515M, GRS515R, GRS515SP, GRS614MP, GRS700, GRS700K15, GRX316SP, GRX3P, GRX416SP, GRX520, GRX500, GRX516SP, GRX520, GRX520/B, GRX550, GRX560, GRX570, GRX580K, GRX590, GRX5P, GRX600, GRX650, GRX650, GRX670, GRX690, GRX700, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PCG-705, PCG-705/S, PCG707, PCG-713, PCG-713/32, PCG-715, PCG-719, PCG-719/64, PCG-721, PCG-723, PCG-723/BP, PCG-7726, PCG-729, PCG-731, PCG-733, PCG-733A, PCG-733G, PCG-737, PCG-737/A4G, PCG-767, PCG-777/BP, PCG-803, PCG-808, PCG-861/BP, PCG-862, PCG-864, PCG-868, PCG-881/BP, PCG-883, PCG-885, PCG-887, PCG-887/BP, PCG-887/BP2, PCG-888, PCG-F14/BP, PCG-F16/BP, PCG-F20/BP2, PCG-F23/BP, PCG-F23/BP2, PCG-F26/BP, PCG-F26/BP2, PCG-F34/BP, PCG-36/BP, PCG-37/BP, PCG-F50/BP, PCG-F50A/BP, PCG-F55/BP, PCG-F57/BP, PCG-F59DK, PCG-F6/BP, PCG-F60/BP, PCG-F65/BP, PCG-F66/BPK, PCG-F670T, PCG-F70/BP, PCG-F70A/BP, PCG-F75/BP, PCG-F76/BP, PCG-F79/BPK, PCG-FR215E, PCG-FR215H, PCG-FR215M, PCG-FR215S, PCG-FR295MP, PCG-FR315M, PCG-FR33, PCG-FR33/B, PCG-FR55B, PCG-FR55E, PCG-FR55E/B, PCG-FR55G, PCG-FR55G/B, PCG-FR55J, PCG-FR55J/B, PCG-FR55R/P, PCG-FR700, PCG-FR700H, PCG-FR700S, PCG-FR720, PCG-FR720L, PCG-FR720S, PCG-FR77E/B, PCG-FR77G/B, PCG-FR77J/B, PCG-FR820L, PCG-FR820S, PCG-FR825P, PCG-FR825P/B, PCG-FRV25, PCG-FX11/BP, PCG-FX11G/BP, PCG-FX11J, PCG-FX11S/BP, PCG-FX11V, PCG-FX11VA, PCG-FX240, PCG-FX240K, PCG-FX33G/BP, PCG-FX33S/BP, PCG-FX33V/BP, PCG-FX390, PCG-FX390K, PCG-FX390P, PCG-FX50G/K, PCG-FX55/BP, PCG-FX55A/BP, PCG-FX55G/BP, PCG-FX55J/B, PCG-FX55S/BP, PCG-FX55V/BP, PCG-FX55Z/BP, PCG-FX55ZA, PCG-FX60G/K, PCG-F77/BP, PCG-FX770TK, PCG-FX77G/BP, PCG-FX77S/BP, PCG-FX77V/BP, PCG-FX77Z, PCG-FX77Z/BP, PCG-FX800, PCG-FX880K, PCG-FX90/BPK, PCG-FX900, PCG-FX900H, PCG-FX90G/K, PCG-FX950, PCG-FX950H, PCG-FX990, PCG-99V/BP, PCG-FXA10, PCG-FXA10H, PCG-GRS50/B, PCG-GRS500, PCG-GRS500/P, PCG-GRS52V/P, PCG-GRS55/B, PCG-GRS70/P, PCG-GRS72V/P, PCG-GRS900, PCG-GRS900/P, PCG-GRX102/P, PCG-GRX1P, PCG-GRX3HP, PCG-GRX3LP, PCG-GRX3P, PCG-GRX51/BP, PCG-52G/B, PCG-5LP, PCG-GRX5P, PCG-GRX71, PCG-GRX72/P, PCG-GRX81G/P, PCG-GRX90/P, PCG-GRX91G/P, PCG-GRX92G/P, PCG-NV190, PCG-NV55/BP, PCG-NV55E/B, PCG-NV77M/BP, PCG-NV7EL, PCG-NV7L, PCG-NV90, PCG-NV90E, PCG-NV95EN, PCG-NV99E/B, PCG-NV99M/BP, PCG-QR1/BP, PCG-QR1E/BP, PCG-QR1S/BP, PCG-QR3/BP, PCG-QR3E/BP, PCG-QR3S/BP, PCG-R505/ABD, PCG-R505/ABW, PCG-R505/ASP, PCG-R505/BW, PCG-R505/SP, PCG-R505AFH, PCG-R505AFT, PCG-R505AGT, PCG-R505CT, PCG-R505SDT, PCG-R505F/BD, PCG-R505F/SP, PCG-R505FR, PCG-R505FR/D, PCG-R505GL, PCG-R505GLK, PCG-R505J/BD, PCG-R505MFL, PCG-R505MGH, PCG-R505MGL, PCG-R505MP, PCG-R505Q/B, PCG-R505Q/BD, PCG-R505R/AK, PCG-R505R/DK, PCG-R505R/GK, PCG-R505R/K, PCG-R505S/PD, PCG-R505TFL, PCG-R505TFP, PCG-R505V/BD, PCG-R505V/FK,	209 (cont.)	PCG-R505V/J/K, PCG-R505VM/K, PCG-R505VM/P, PCG-R505W/P, PCG-R505W/PD, PCG-R505X/P, PCG-R505X/PG, PCG-TR5GP, PCG-XE17, PCG-XR1, PCG-XR100E/K, PCG-XR100F/K, PCG-XR1E/BP, PCG-XR1F/BP, PCG-XR1G, PCG-XR1S/BP, PCG-XR1SA/BP, PCG-XR1Z/BP, PCG-XR7, PCG-XR7E/K, PCG-XR7F/K, PCG-XR7G, PCG-XR7S, PCG-XR7Z/BP, PCG-XR7Z/K, PCG-XR9, PCG-XR9E/K, PCG-XR9F/K, PCG-XR9G, PCG-XR9S, PCG-XR9Z/K, PCG-Z505C/BP, PCG-Z505CR/K, PCG-Z505CR/P, PCG-Z505D, PCG-Z505F, PCG-Z505FX, PCG-Z505G/BP, PCG-Z505GAT, PCG-Z505GATH, PCG-Z505GATM, PCG-Z505GR/K, PCG-Z505J/BP, PCG-Z505JL, PCG-Z505JX, PCG-Z505NB/P, PCG-Z505NR, PCG-Z505V/BP, PCG-Z505V/BW, PCG-Z505VR/K, PG32, QR10, QR20, R500, R505B/P, R505CT, R505D, R505DS, R505DSK, R505DT, R505J, R505MP, R505MXC, R505T, R505TE, R505TEK, R505TFP, R505TS, R505TSCP, R505TZCP, R600HEK, R600HEP, R600HFPD, R600HMPD, R600MX, VGC-LB50, VGC-LB50B, VGC-LB90S, VGN-A115B, VGN-A115S, VGN-A115Z, VGN-A117S, VGN-A130, VGN-A130B, VGN-A130B28, VGN-A130P, VGN-A140, VGN-A140B, VGN-A140P, VGN-A150, VGN-A150G, VGN-A15L/P, VGN-A160, VGN-A170, VGN-A170B, VGN-A170P, VGN-A17GP, VGN-A17L/P, VGN-A17SP, VGN-A190, VGN-A195EP, VGN-A195HP, VGN-A197VP, VGN-A197X/P, VGN-A19GP, VGN-A19LP, VGN-A19SP, VGN-A215M, VGN-A215Z, VGN-A217M, VGN-A217S, VGN-A21C, VGN-A230B1, VGN-A230P, VGN-A240, VGN-A250, VGN-A260, VGN-A270, VGN-A270B, VGN-A270P, VGN-A290, VGN-A295HP, VGN-A297X/P, VGN-A29LP, VGN-A29SP, VGN-A317M, VGN-A39GP, VGN-A417P, VGN-A417S, VGN-A497X/P, VGN-A49GP, VGN-A50B, VGN-A517B, VGN-A517M, VGN-A517S, VGN-A51S/P, VGN-A51S, VGN-A59GP, VGN-A600, VGN-A600091, VGN-A600B, VGN-A600P, VGN-A60B, VGN-A60GP, VGN-A60PS, VGN-A60S, VGN-A617B, VGN-A617M, VGN-A617S, VGN-A61B, VGN-A62B, VGN-A63, VGN-A690, VGN-A70P, VGN-A70PS, VGN-A71PS, VGN-A71S, VGN-A72PB, VGN-A72PS, VGN-A72S, VGN-A73PS, VGN-A73S, VGN-A74S, VGN-A74S, VGN-A790, VGN-AS33B, VGN-AS34B, VGN-AS53B, VGN-AS53PS, VGN-AS53S, VGN-AS54B, VGN-AS54PS, VGN-AS54S, VGN-AS72BP, VGN-AX570G, VGN-AX580G, VGN-BX143, VGN-BX145CP, VGN-BX168GP, VGN-BX194VP, VGN-BX195EP, VGN-BX195VP, VGN-BX195XP, VGN-BX196SP, VGN-BX196VP, VGN-BX197X/P, VGN-BX294VP, VGN-BX295SP, VGN-BX295VP, VGN-BX296VP, VGN-BX296XP, VGN-BX297X/P, VGN-BX394VP, VGN-BX396BP, VGN-BX396VP, VGN-BX396XP, VGN-BX397X/P, VGN-BX41VN, VGN-BX540B, VGN-BX541A, VGN-BX543B, VGN-BX546B, VGN-BX560B, VGN-BX561B, VGN-BX563B, VGN-BX565B, VGN-BX567B, VGN-BX570B, VGN-BX90PS, VGN-BX90S, VGN-C140G/B, VGN-C150P/B, VGN-C190, VGN-C190P/H, VGN-C1S/G, VGN-C1S/H, VGN-C1S/P, VGN-C1S/W, VGN-C1Z/B, VGN-C210E/H, VGN-C220E/H, VGN-C240E/B, VGN-C250N/B, VGN-C290, VGN-C291NW/H, VGN-C2/G, VGN-C2S/H, VGN-C2S/L, VGN-C2S/P, VGN-C2S/W, VGN-C2Z/B, VGN-E50B/B, VGN-E50B/D, VGN-E50B/S, VGN-E51B/D, VGN-E51B/S, VGN-E70B/B, VGN-E70B/S, VGN-E71B/G, VGN-E71B/S, VGN-E72B/D, VGN-E72B/G, VGN-E72B/S, VGN-E81B/B, VGN-E91B/B, VGN-E92B/B, VGN-FA11S, VGN-FA20, VGN-FA25TP, VGN-FA28B, VGN-FA28H, VGN-FA30B, VGN-FA31B, VGN-FA31H,		
206	OmniBook: 2100, 2103, 2105, 3000, 3100, 3101, 4000C, 4100, 4101, 4103, 4105, 4150, 4150B, 500, 510, 6000, 6000B, 6000C, 6100, 7100, 7103, 7150, 900, 900B, N3000, VT6200, XE4400 BTO, XE-DA, XE2-DB, XE2-DC, XE2-DD, XE2-DE, XE2-DI, XE3, XE3-GD, XE3-GF, XE3B, XE3C, XE4100, XE4200, XE4400, XE4500, XT1000, XT1500, XT6200 Pavilion: 2105US, 3101, 4101, 4103, 4105, 5159, N3110, N3150, N3190, N3210, N3215, N3220, N3250, N3270, N3290, N3295, N3310, N3350, N3370, N3380, N3390, N3402, N3410, N3438, N3478, N3490, N5000 BTCCO, N5124, N5125, N5130, N5135, N5140, N5150, N5159, N5170, N5190, N5195, N5240, N5241, N5250, N5261, N5270, N5271, N5290, N5295, N5310, N5311, N5331, N5340, N5341, N5350, N5351, N5361, N5371, N5381, N5390, N5401, N5402, N5402L, N5412, N5415, N5420, N5421, N5421L, N5422, N5422L, N5425, N5430, N5431L, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5451, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N5511L, N5584, N6190, N6195, N6300 BTO, N66395, N66396, N66397, N6398, N6399, N6400, N6401, N6402, N6403, N6404, N6490, XF125, XF145, XF235, XF255, XF315, XF325, XF328, XF335, XH136, XH156, XH176, XH215, XH216, XH226, XH355, XH365, XH395, XH455, XH485, XH525, XH535, XH545, XH555, XH575, XH625, XH675, XT1115, XT118, XT125, XT128, XT155, XT178, XT183, XT188, XT236, XT276, XT345, XT375, XT395, XT412, XT4316WM, XT4345QV, XT512, XT5300, XT5335QV, XT5366, XT5366WM, XT5377, XT5377QV, XT545, XT5477WM,	203	510	204	ThinkPad: 240, 240X, 290, 365, 365XD, 380, 380D, 380E, 380ED, 380XD, 380Z, 385, 385D, 385ED, 385XD, 390, 390E, 390X, 560, 560E, 560X, 560Z, 570, 600, 600E, 600X, 701, 770, 770E, 770ED, 770X, 770Z, A20, A20m, A20p, A21, A21e, A21m, A21p, A22, A22e, A22m, A22p, A30, A30p, A31, A31p, A50, A50p, A51p, i1200, i1300, i1400-2621, i1500-2621, i1720, i1721, R30, R31, R32, R40, R40e, R50, R50e, R50p, R51, R51e, R52, T20, T21, T22, T23, T30, T40, T40p, T41, T41p, T42, T42p, T43, T43p, X20, X21, X22, X23, X24, X30, X31, X32, X40, X41, X41 Tablet, Transnote	205	ToughBook: CF-29, CF-30, CF-50, CF-73, CF-R1, CF-R4, CF-T1, CF-T2, CF-W4, T4, T5, W5, Y5	209	ToughBook: CF-V21, CF-V21P
			IBM/LENOVO						
			ThinkPad: R60, R60e, R61, T60, T60p, T61, X60, X60 Tablet, X60s, Z60m, Z60T, Z61e, Z61m, Z61p, Z61t, 3000 C200, 3000C C100, 3000N N100, 3000V V100						
			PANASONIC						
			ToughBook: CF-29, CF-30, CF-50, CF-73, CF-R1, CF-R4, CF-T1, CF-T2, CF-W4, T4, T5, W5, Y5						
			SONY						
			VAIO: 705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 81, 812, 818, 838, A17GP, A19GP, A29GP, A29TP, C1XW, F150, F160, F180, F190, F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660, F670, F680, F690, F701, F707, F709, F709K, F801, F801A, F807, F807K, F808K, F809K, FR-55G, FR-55G/B, FR-55J, FR-55J/B, FR-55R/P, FR-77G/B, FR-77J/B, FR-102, FR105, FR130, FX101, FX103, FX105K, FX108K, FX109K, FX120, FX140, FX150, FX170, FX190, FX200, FX201, FX203, FX203K, FX205K, FX209K, FX220K, FX270, FX301, FX401, FX405, FX501, FX502, FX505,						

Laptop Connector Compatibility Chart (continued)

TIP	SONY (cont.)	TIP	SONY (cont.)	TIP	TOSHIBA (cont.)	TIP	TOSHIBA
209 <i>(cont.)</i>	VGN-FE31M, VGN-FE31Z, VGN-FE41E, VGN-FE41M, VGN-FE41S, VGN-FE41Z, VGN-FE50B, VGN-FE550G, VGN-FE570G, VGN-FE590GC, VGN-FE590P03, VGN-FE590PA, VGN-FE590PB, VGN-FE590PC, VGN-FE660G, VGN-FE670G, VGN-FE690, VGN-FE690GB, VGN-FE690PB, VGN-FE770G, VGN-FE780G, VGN-FE790, VGN-FE790GN, VGN-FE790PL, VGN-FE855E/H, VGN-FE870E/H, VGN-FE880E/H, VGN-FE890, VGN-FE90PS, VGN-FE90S, VGN-FJ10B, VGN-FJ11/W, VGN-FJ170/B, VGN-FJ180P/G, VGN-FJ180P/L, VGN-FJ180P/R, VGN-FJ180P/W, VGN-FJ1S/W, VGN-FJ1Z/W, VGN-FJ21B/G, VGN-FJ21B/L, VGN-FJ21B/R, VGN-FJ250P/B, VGN-FJ270P/B, VGN-FJ290, VGN-FJ290P1/G, VGN-FJ290P1/L, VGN-FJ290P1/R, VGN-FJ290P1/V, VGN-FJ290P1/W, VGN-FJ3S/W, VGN-FJ56C, VGN-FJ57C, VGN-FJ57SP, VGN-F58C, VGN-FJ58GP, VGN-FJ58SP, VGN-FJ66GP, VGN-FJ66GP/W, VGN-FJ67GP/W, VGN-FJ77GP/B, VGN-FJ78GP/B, VGN-FJ78GP/W, VGN-FJ78GP/L, VGN-FJ78GP/R, VGN-FJ79TP/W, VGN-FJ79TP/W, VGN-FJ90PS, VGN-FJ90S, VGN-FJ91PS, VGN-FJ91S, VGN-FR825P, VGN-FR825P, VGN-FS115B, VGN-FS115E, VGN-FS115M, VGN-FS115S, VGN-FS115Z, VGN-FS15C, VGN-FS15GP, VGN-FS15L, VGN-FS15SP, VGN-FS18CP, VGN-FS18GP, VGN-FS18LP, VGN-FS18SP, VGN-FS195VP, VGN-FS195XP, VGN-FS20, VGN-FS21, VGN-FS215B, VGN-FS215E, VGN-FS215M, VGN-FS215MR, VGN-FS215S, VGN-FS215SR, VGN-FS215Z, VGN-FS21B, VGN-FS22B, VGN-FS22VB, VGN-FS23B, VGN-FS25C, VGN-FS25GP, VGN-FS25SP, VGN-FS285B, VGN-FS285E, VGN-FS285H, VGN-FS285M, VGN-FS28C, VGN-FS28GP, VGN-FS28SP, VGN-FS295VP, VGN-FS295XP, VGN-FS30B, VGN-FS315B, VGN-FS315E, VGN-FS315H, VGN-FS315M, VGN-FS315MR, VGN-FS315S, VGN-FS315Z, VGN-FS31B, VGN-FS32B, VGN-FS33B, VGN-FS35C, VGN-FS35GP, VGN-FS35SP, VGN-FS38C, VGN-FS38GP, VGN-FS38SP, VGN-FS395VP, VGN-FS415B, VGN-FS415E, VGN-FS415M, VGN-FS415S, VGN-FS43, VGN-FS485B, VGN-FS48GP, VGN-FS495VP, VGN-FS500, VGN-FS500B, VGN-FS500P12, VGN-FS50B, VGN-FS515B, VGN-FS515E, VGN-FS515H, VGN-FS51B, VGN-FS520B, VGN-FS52B, VGN-FS530B, VGN-FS53B, VGN-FS540P, VGN-FS550, VGN-FS550F, VGN-FS550P, VGN-FS570, VGN-FS5610FP, VGN-FS5615FP, VGN-FS620P/W, VGN-FS625B/W, VGN-FS630/W, VGN-FS635B/W, VGN-FS640/W, VGN-FS640FP, VGN-FS645P/H, VGN-FS650F, VGN-FS655FP, VGN-FS660/W, VGN-FS660P/W, VGN-FS670FG, VGN-FS675P/H, VGN-FS680/W, VGN-FS690, VGN-FS690B, VGN-FS690P, VGN-FS70B, VGN-FS710/W, VGN-FS710FP, VGN-FS715/W, VGN-FS715F, VGN-FS71B, VGN-FS720/W, VGN-FS730/W, VGN-FS730F, VGN-FS740/W, VGN-FS740FP, VGN-FS742/W, VGN-FS745P/H, VGN-FS750F, VGN-FS750P/W, VGN-FS755FP, VGN-FS760/W, VGN-FS770/W, VGN-FS770FG, VGN-FS775P/H, VGN-FS790, VGN-FS810/W, VGN-FS810F/P, VGN-FS812F, VGN-FS815F, VGN-FS830/W, VGN-FS840/W, VGN-FS850, VGN-FS850/W, VGN-FS850P, VGN-FS850P/W, VGN-FS875P/H, VGN-FS8900, VGN-FS8900P3, VGN-FS8900P4, VGN-FS8900P5, VGN-FS90PS, VGN-FS90S, VGN-FS91PSY, VGN-FS91S, VGN-FS920, VGN-FS92PS, VGN-FS92S, VGN-FS930F, VGN-FS940, VGN-FS960P, VGN-FS970P, VGN-FS980, VGN-FS990, VGN-FS910, VGN-FS910P, VGN-FS910S, VGN-FZ130E/B, VGN-FZ160E/B, VGN-FZ180E/B, VGN-FZ19VN, VGN-FZ110G/W,	209 <i>(cont.)</i>	VGN-N11H/W, VGN-N11M/W, VGN-N11S/W, VGN-N130G/W, VGN-N130P/B, VGN-N150G/W, VGN-N150P/B, VGN-N160G/W, VGN-N170G/T, VGN-N170G/W, VGN-N19EP/B, VGN-N19VP/B, VGN-N21E/W, VGN-N21M/W, VGN-N21S/W, VGN-N220E/B, VGN-N220E/W, VGN-N230N/B, VGN-N250E/W, VGN-N250N/B, VGN-N270E/T, VGN-N270E/W, VGN-N29VN/B, VGN-N31S/W, VGN-N320E/B, VGN-N320E/W, VGN-N350E/B, VGN-N350E/T, VGN-S170P, VGN-S21Z/W, VGN-S380, VGN-S380B, VGN-S38GP, VGN-S38GP/B, VGN-S38LP/B, VGN-S38SP, VGN-S3HP, VGN-S3VP, VGN-S3XP, VGN-S430P/S, VGN-S45, VGN-S45SP, VGN-S46, VGN-S460, VGN-S460/B, VGN-S460P/B, VGN-S46GP/S, VGN-S470P/S, VGN-S470P/SKIT, VGN-S470P/SKIT7, VGN-S47SP, VGN-S48, VGN-S480, VGN-S480B, VGN-S48GP/B, VGN-S49, VGN-S4HP, VGN-S4HP/B, VGN-S4HRP/B, VGN-S4M/S, VGN-S4VP/B, VGN-S4XP, VGN-S4XRP/B, VGN-S53B/S, VGN-S54B/S, VGN-S55, VGN-S550P/S, VGN-S55B/S, VGN-S550P/S, VGN-S55B/S, VGN-S55SP/S, VGN-S56, VGN-S560P/B, VGN-S56GP/S, VGN-S570P/S, VGN-S57SP/B, VGN-S58, VGN-S580, VGN-S8GP/B, VGN-S59, VGN-S5HP, VGN-S5M/S, VGN-S5VP, VGN-S5XP/B, VGN-S660/B, VGN-S67GP/S, VGN-S67TP, VGN-S72PB/B, VGN-S73PB/B, VGN-S92PS/S, VGN-S92PSY, VGN-S92PSY1, VGN-S92PSY2, VGN-S92S/S, VGN-S93PS/S, VGN-S93PSY, VGN-S93S/S, VGN-S94PS, VGN-SZ110/B, VGN-SZ120P, VGN-SZ120P/B, VGN-SZ140, VGN-SZ140PC, VGN-SZ140PD, VGN-SZ160P/C, VGN-SZ210P/B, VGN-SZ220/B, VGN-SZ230P/B, VGN-SZ23TP/B, VGN-SZ240, VGN-SZ250P/C, VGN-SZ260P, VGN-SZ26TP/C, VGN-SZ270P/C, VGN-SZ280P/C, VGN-SZ281P/X, VGN-SZ28TP/C, VGN-SZ2VP/X, VGN-SZ320P/B, VGN-SZ330P/B, VGN-SZ340, VGN-SZ360P/C, VGN-SZ370P/C, VGN-SZ381P/X, VGN-SZ390, VGN-SZ390PW1, VGN-SZ3HP/B, VGN-SZ3VP/X, VGN-SZ3VWP/X, VGN-SZ3XP/C, VGN-SZ3XWP/C, VGN-SZ430N/B, VGN-SZ440, VGN-SZ450N/C, VGN-SZ460N/C, VGN-SZ470N/C, VGN-SZ480, VGN-SZ491N/X, VGN-SZ4MN/B, VGN-SZ4VN/X, VGN-SZ4VWN/X, VGN-SZ4XN/C, VGN-SZ4XWN/C, VGN-SZ51B/B, VGN-SZ70B/B, VGN-SZ71B/B, VGN-SZ80PS, VGN-SZ80S, VGN-SZ81PS, VGN-SZ81S, VGN-SZ90PS, VGN-SZ90S, VGN-SZ91PS, VGN-SZ91S, X9, X18, X29, XE7, XE17, XG9, XG18, XG19, XG28, XG28K, XG29, XG29K, XG38, XG39, XG39K, XG500, XG700, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK	206 <i>(cont.)</i>	3000-S304, 3000-S353, 3000-X11, 3000-X4, 3000-S303, 3000-S304, 3000-S307, 3000-S403, 35D0D, A100-003, A100-011, A100-036, A100-151, A100-163, A100-165, A100-181, A100-188, A100-193, A100-209, A100-212, A100-218, A100-220, A100-232, A100-241, A100-250, A100-269, A100-270, A100-274, A100-287, A100-290, A100-294, A100-295, A100-303, A100-436, A100-437, A100-467, A100-500, A100-507, A100-508, A100-510, A100-513, A100-521, A100-522, A100-523, A100-524, A100-525, A100-533, A100-534, A100-535, A100-551, A100-561, A100-565, A100-570, A100-571, A100-590, A100-590, A100-597, A100-649, A100-661, A100-662, A100-669, A100-712, A100-717, A100-766, A100-768, A100-784, A100-786, A100-787, A100-788, A100-81, A100-813, A100-847, A100-906, A100-906, A100-912, A100-920, A00-S221TD, A100-S231TD, A100-S811TD, A100-SP621, A100-ST1041, A100-ST3211, A100-VA1, A100-VA104C, A100-VA45, A100-VA1, A105-2715, A105-S101, A105-S1013, A105-S1014, A105-S171, A105-S1712, A105-S2011, A105-S2021, A105-S2031, A105-S2051, A105-S2061, A105-S2071, A105-S2081, A105-S2091, A105-S2141, A105-S2201, A105-S2231, A105-S2236, A105-S2712, A105-S2713, A105-S2716, A105-S2717, A105-S361, A105-S3611, A105-S4022, A105-S4102, A105-S4132, A110-101, A110-110, A110-133, A110-142, A110-162, A110-177, A110-178, A110-195, A105-203, A110-212, A110-S225, A110-228, A110-253, A110-260, A110-274, A110-275, A110-277, A110-289, A110-293, A110-294, A110-334, A110-339, A110-381, A110-ST1111, A135-S2256, A135-S2266, A135-S2276, A135-S2286, A135-S2296, A135-S2306, A135-S4407, A135-S4417, A135-S4427, A135-S4437, A135-S4447, A135-S4457, A135-S4467, A135-S4477, A135-S4478, A135-S4487, A135-S4488, A135-S4517, A200-10W, A200-10X, A200-10Z, A200-11C, A200-130, A200-13R, A200-14D, A200-14E, A200-1AE, A200-1BP, A200-1CR, A205-S4587, A60-127, A80-S178TD, L10-L107, L10-114, L10-132, L10-151, L10-190, L10-282, L100-103, L100-104, L100-105, L100-111, L100-121, L100-140, L100-141, L100-165, L100-165, L100-170, L100-171, L100-173, L100-175, L100-179, L100-194, L10Q, L15-S104, L20-101, L20-112, L20-118, L20-120, L20-121, L20-135, L20-149, L20-153, L20-155, L20-157, L20-159, L20-173, L20-181, L20-182, L20-183, L20-188, L20-196, L20-204, L20-205, L20-217, L20-256, L20-268, L20-S310TD, L20-SP119, L20-SP231, L25-S119, L25-S1192, L25-S1195, L25-S1196, L25-S121, L25-S1211, L25-S1216, L25-S139, L25-SP141, L30-101, L30-105, L30-10S, L30-10X, L30-113, L30-114, L30-115, L30-11D, L30-11E, L30-11E, L30-11G, L30-134, L30-142, L35-S1054, L35-S2151, L35-S2161, L35-S2171, L35-S2174, L35-S2194, L35-S2316, L35-S2366, M100-152, M100-178, M100-179, M100-180, M100-195, M100-221, M100-222, M100-S1011, M100-S1021, M100-S1021, M100-S1061, M100-S1064, M100-S1071, M30X, M30X-102, M30X-104, M30X-105, M30X-106, M30X-107, M30X-108, M30X-111, M30X-113, M30X-115, M30X-118, M30X-122, M30X-124, M30X-125, M30X-127, M30X-128, M30X-129, M30X-130, M30X-131, M30X-134, M30X-142, M30X-143, M30X-144, M30X-148, M30X-150, M30X-154, M30X-155, M30X-156, M30X-159, M30X-161, M30X-162, M30X-163, M30X-165, M30X-166, M30X-167, M30X-168, M30X-169, M30X-170, M30X-173, M30X-174, M30X-S181ST, M30X-S191TD, M30X-S221TD, M35X-S109, M35X-S111, M35X-S114, M35X-S149, M35X-S1491,	206 <i>(cont.)</i>	M35X-S1492, M35X-S161, M356X-S1611, M35X-S163, M35X-S1631, M35X-S309, M35X-S3091, M35X-S3111, M35X-S3111, M35X-S329, M35X-S3291, M35X-S349, M35X-3491, M35X-SP181, M40X-112, M40X-115, M40X-116, M40X-119, M40X-129, M40X-154, M40X-159, M40X-161, M40X-163, M40X-166, M40X-175, M40X-183, M40X-184, M40X-231, M40X-250, M40X-251, M45-S165, M45-S1651, M45-S169, M45-S1691, M50-101, M50-102, M50-105, M50-106, M50-108, M50-109, M50-113, M50-115, M50-122, M50-124, M50-126, M50-137, M50-138, M50-141, M50142, M50-143, M50-145, M50-148, M50-156, M50-163, M50-164, M50-168, M50-170, M50-176, M50-180, M50-181, M50-182, M50-183, M50-187, M50-196, M50-198, M50-203, M50-215, M50-226, M50-227, M50-S208, M50-231, M50-247, M50-252, M55-S1101, M55-S139, M60P-M740, M60-104, M60-105, M60-132, M60-134, M60-135, M60-139, M60-144, M60-164, M60-S6111TD, M60-S6112TD, M60-S611TD, M65-S809, M65-S8091, M65-S8092, M65-S821, M65-S8211, M65-S8212, M65-S9062, M65-S9063, M65-S9064, M65-S9065, M65-S909, M65-S9091, M65-S9092, M65-S9093, M65-SP959, M70-122, M70-129, M70-131, M70-144, M70-151, M70-152, M70-159, M70-160, M70-168, M70-169, M70-175, M70-181, M70-186, M70-187, M70-189, M70-190, M70-191, M70-192, M70-193, M70-194, M70-196, M70-212, M70-217, M70-236, M70-238, M70-239, M70-252, M70-258, M70-267, M70-340, M70-343, M70-348, M70-354, M70-356, M70-376, M70-394, M70-395, M70-396, P100-223, P100-253, P100-284, P100-340, R20-110, R20-112, U200-163, U200-165, U200-181 Satellite Pro: A100, A100-229, A100-240, A100-242, A100-244, A100-247, A100-262, A100-263, A100-264, A100-296, A100-297, A100-415, A100-501, A100-511, A100-514, A100-518, A100-531, A100-532, A100-536, A100-538, A100-545, A100-564, A100-574, A100-577, A100-622, A100-707, A100-708, A100-722, A100-848, A100-908, A100-106, A120-169, L10, L10-103, L10-118, L10-175, L10-178, L10-184, L10-185, L100-132, L100-176, L20, L20-102, L20-103, L20-137, L20-148, L20-184, L20-189, L20-211, L20-258, L20-259, M40, M40-274, M40-275, M40-280, M40-301, M40-325, M40X-132, M40X-134, M40X-165, M40X-167, M40X-168, M40X-169, M40X-260, M50-238, M50-239, M50-240, M50-241, M50-242, M70, M70-109, M70-110, M70-113, M70-125, M70-126, M70-132, M70-134, M70-137, M70-154, M70-178, M70-198, M70-199, M70-220, M70-235, M70-237, M70-275, M70-299, M70-307, M70-317, M70-325, M70-326, M70-327, M70-331, M70-332, M70-333, U200-129, U200-132, U200-155, U200-182 Tecra: A6-141, A7-110, A7-112, A7-114, A7-202, A7-209, A7-221, A7-232, A7-248, A8-117, A8-127, A8-129, A8-130, A8-132, A8-143, A8-150, A8-159, A8-183, A8-185, A8-210, L2-S011, M5-118, M5-119, M5-292, M5-383, M5-384, M5-415, M5-417, M7-117, M7-121, M7-132, M7-133, M7-141 Dynabook Satellite: 1800, 1830, 1850, 1860, 1870, 2140, 2400, 2410, 2800, 5000, 5100, A10, A50-01900M, A50-01900N, A50-01F00M, A50-01F00N, A50-02700M, A50-03900N, A50-08K00N, A50-08L00N, M30 Dynabook Satellite Pro: 440, 460, 480, 490 Dynabook SS: 1600, 1610, 2000, 2010, 2100, 2110, 2120, 3500, 4000, M3, M10, MX, S, S4, S5, S6, S7, S8, S9, SX Equium: A100-027, A100-147, A100-306, A100-338, L10-206, L10-273, L10-300
		206	TOSHIBA Dynabook Satellite: 1400, 1410 Equium: A100-549, A100-602, L10-142, L10-200, L100-186, L20-197, L20-198, L20-264, M40X-149, M50-159, M50-192, M50-216, M50-218, M50-244, M70-173, M70-337, M70-339, M70-364 Libretto: U100-105, U100-111 Portégé: M400-100, M400-103, M400-105, M400-109 Satellite: 1000-S157, 1000-S158, 1005-S157, 1005-S158, 1100, 1100-S101, 1100-Z6, 1105, 1200, 1200-S121, 1200-S122, 1605CDS, 1520CDS, 1625CDT, 1640CDT, 1670CDT, 1670CDS, 1675CDS, 1690CDT, 1695CDT, 1700-200, 1700-300, 1710CDS, 1715XCDS, 1730, 1730CDT, 1735, 1750, 1755, 3000-100, 3000-400, 3000-514,				

Laptop Connector Compatibility Chart (continued)

TIP	TOSHIBA (cont.)	TIP	TOSHIBA (cont.)	TIP	TOSHIBA (cont.)	TIP	TOSHIBA (cont.)
205 (cont.)	<p>Libretto: 60, L, U100, U100-108, U100-S213, U105</p> <p>Portégé: 2000, 2010, 3500 Tablet, 3505 Tablet, 4000, 4005, 4010, 7000CT, 7010CT, 7020CT, 7140CT, 7200CT/Cte, 7220Cte, A100, A200, A200-120, M100, M100-101, M100-104, M100-105, M100-106, M100-107, M100-112, M100-122, M200, M200 P-M750, M200-100, M200-101, M200-102, M200-105, M200-122, M200-142, M200-152, M200-160, M200-171, M200-172, M200-173, M200-19T114, M200-19T294, M200-S218TD, M200-S838, M205, M205-S809, M205-S810, M300, M300-100, M300-101, M300-102, M300-103, M300-104, M300-105, M400-139, M400-EZ5031, M400-S4031, M400-S4032, M400-S4032, M400-S5032, M400-S933, M400-ST4001, M400-ST4035, M400-ST9113, M400-S8003, R100, R100-102, R150, R200, R200-110, R200-S2031, R200-S2062, R200-S234, R205-S2062, R205-S209, R400-S4831, R400-S4832, R400-S4833, R400-S4931, R500-S5001X, RS100, S100-S1133, S100-S113TD, S100-S213TD</p> <p>Qosmio: E10, E10-102, E10-P440, E15-AV101, F10-100, F10-101, F10-103, F10-104, F10-105, F10-106, F10-114, F10-120, F10-121, F10-122, F10-124, F10-125, F10-126, F10-128, F10-130, F10-131, F10-132, F10-136, F10-P540, F10-AV201, F20-101, F20-103, F20-104, F20-110, F20-111, F20-130, F20-132, F20-133, F20-136, F20-137, F20-138, F20-140, F20-141, F20-144, F20-148, F20-149, F20-153, F20-154, F20-155, F20-156, F20-159, F20-161, F20-P540, F25-AV205, F30-117, F30-127, G20-P640</p> <p>Satellite: 1400, 1400-103, 1400-153, 1400-203, 1400-253S, 1400-553S, 1400-S151, 1400-S152, 1405, 1405-S151, 1405-S152, 1405-S171, 1405-S172, 1410, 1410-303, 1410-303x, 1410-304, 1410-354, 1410-401, 1410-554, 1410-604, 1410-704, 1410-714, 1410-801, 1410-802, 1410-814, 1410-902, 1410-S102, 1410-S103, 1410-S105, 1410-S106, 1410-S173, 1410-S174, 1410-S203, 1415, 1415-S105, 1415-S106, 1415-S115, 1415-S173, 1415-S174, 1550CDS, 1555, 1555CDS, 1800, 1800-100, 1800-254S, 1800-314, 1800-354S, 1800-364E, 1800-400, 1800-412, 1800-452E, 1800-514, 1800-554S, 1800-614, 1800-654S, 1800-700, 1800-712, 1800-752S, 1800-814, 1800-921, 1800-S203, 1800-S204, 1800-S206, 1800-S207, 1800-S253, 1800-S254, 1800-S256, 1800-S274, 1805, 1805-S154, 1805-S177, 1805-S203, 1805-S204, 1805-S207, 1805-S208, 1805-S253, 1805-S254, 1805-S255, 1805-S273, 1805-S274, 1805-S278, 200, 2060, 2065, 2100, 2105, 2140, 2140XCDS, 2180CDT, 220, 220CT, 2210, 2210CDT/XCDS, 2230, 2250, 2250XCDS, 225CDS, 2400, 2405, 2410, 2410-303, 2410-304, 2410-304S, 2410-404, 2410-413, 2410-414, 2410-514, 2410-515, 2410-601, 2410-603, 2410-702, 2410-703, 2410-S206, 2410-S205, 2410-S403, 2410-S453, 2415, 2415-S205, 2430, 2450, 2450-101, 2450-114, 2450-201, 2450-202, 2450-401, 2450-S103, 2450-S203, 2450-S303, 2450-S402, 2455, 2455-S3001, 2455-S305, 2455-S306, 2500CDS, 2500CDT, 2505CDS, 2505CDT, 2510, 2515CDS, 2520, 2530, 2535CDS, 2540, 2545, 2550, 2590CDS, 2590CDT/CDT/XDVD, 2595CDS, 2595CDT, 2595XDVD, 2610, 2615DVD, 2650, 2655XDVD, 2695, 2710, 2715XDVD, 2740, 2750, 2755DVD, 2770, 2775XDVD, 2800, 2800-S201, 2800-S202, 2805, 2805-S201, 2805-S202, 2805-S301, 2805-S302, 2805-S401, 2805-S402, 2805-S503, 300, 310, 320, 330, 4000CDS, 4000CDS/CDT, 4005CDS, 4005CDS/CDT, 4010CDS, 4010CDS/CDT, 4020CDT, 4025CDT, 4030CDT, 4060, 4070, 4080CDT, 4085,</p>	205 (cont.)	<p>4090XDVD, 4090ZDVD, 4100, 4100XDVD, 5005, 5005-S504, 5005-S507, 5005-S508, 5100-201, 5100-501, 5100-503, 5100-603, 5105, 5105-S501, 5105-S502, 5105-S607, 5105-S608, 5105-S701, 5105-S702, 5105-S901, 5200, 5200-701, 5200-702, 5200-711, 5200-801, 5200-802, 5200-901, 5200-902, 5200-903, 5200-904, 5200-S702, 5205, 5205-S119, 5205-S503, 5205-S504, 5205-S505, 5205-S506, 5205-S703, 5205-S704, 5205-S705, 5205-SP505, 5220, A10, A10-131, A10-501, A10-511, A10-521, A10-S100, A10-S1001, A10-S103, A10-S113, A10-S127, A10-S128, A10-S129, A10-S1291, A10-167, A10-169, A10-S1691, A10-177, A10-178, A10-S203, A10-S213, A10-S223, A10-S403D, A10-S503, A10-S513, A10-S603, A10-S613, A10-S703, A10-S811, A100-033, A100-049, A100-062, A100-065, A100-153, A100-160, A100-169, A100-172, A100-197, A100-200, A100-201, A100-204, A100-207, A100-214, A100-216, A100-225, A100-259, A100-285, A100-447, A100-451, A100-487, A100-496, A100-528, A100-529, A100-583, A100-596, A100-680, A100-688, A100-691, A100-692, A100-694, A100-696, A100-720, A100-756, A100-756A, A100-761, A100-771, A100-773, A100-775, A100-936, A100-969, A100-979, A100-998, A100-P530, A100P540, A100-P545, A100-ST1042, A100-ST8211, A100-TA2, A100-TA6, A100-TA7, A100-TA9, A100-VA3, A100-VA7, A100-VA9, A100-WA3, A105-S2001, A105-S4001, A105-S4004, A105-S4011, A105-S4012, A105-S4014, A105-S4021, A105-S4024, A105-S4034, A105-S4054, A105-S4064, A105-S4074, A105-S4084, A105-S4092, A105-S4094, A105-S4104, A105-S4115, A105-S4134, A105-S4164, A105-S4184, A105-S4201, A105-S4211, A105-S4214, A105-S4244, A105-S4254, A105-S4274, A105-S4284, A105-S4324, A105-S4342, A105-S4344, A105-S4364, A105-S4384, A105-S4397, A105-S4547, A105-S45472, A15, A15-S127, A15-S128, A15-S129, A15-S1291, A15-S1292, A15-S157, A15-S158, A15-S1692, A50, A50-100, A50-101, A50-102, A50-104, A50-105, A50-106, A50-108, A50-109, A50-110, A50-111, A50-112, A50-114, A50-120, A50-122, A50-402, A50-412, A50-432, A50-452, A50-492, A50-502, A50-512, A50-522, A50-523, A50-532, A50-542, A50-543, A50-S135, A50-S310B, A50-S310G, A50-S311G, A50-S330B, A50-S330G, A50-S332B, A50-S333B, A50-S336G, A50-S430B, A50-S432B, A50-S432G, A50-S535B, A50-S535G, A50-S536B, A50-S536G, A50-S537B, A55, A55-S106, A55-S1063, A55-S1066, A55-S129, A55-S1291, A55-S179, A55-S1791, A55-S306, A55-S3061, A55-S3062, A55-S3063, A55-S326, A55-A3261, L10-100, L10-101, L10-102, L10-103, L10-104, L10-105, L10-108, L10-113, L10-117, L10-119, L10-120, L10-121, L10-123, L10-125, L10-130, L10-137, L10-144, L10-146, L10-154, L10-161, L10-167, L10-192, L10-193, L10-194, L10-202, L10-204, L10-205, L10-209, L10-223, L10-224, L10-226, L10-232, L10-269, L10-270, L10-272, L10-281, L10-333, L15-190, M100-P340, M100-P343, M100-P345, M100-ST51111, M100-ST5211, M105-S3001, M105-S3002, M105-S3004, M105-S3011, M105-S3012, M105-S3021, M105-S3031, M105-S3041, M105-S3064, M105-S3074, M105-S3084, M110-ST1161, M115-S3094, M115-S3104, M115-S3144, M115-S3154, M20, M20-S257, M20-S258, M30, M30 Special, M30-100, M30-103, M30-104, M30-105, M30-106, M30-107, M30-114, M30-125, M30-154, M30-164, M30-204, M30-241, M30-261, M30-304, M30-344, M30-354, M30-361, M30-304, M30-344, M30-354, M30-361, M30-404,</p>	205 (cont.)	<p>M30-604, M30-622, M30-642-, M30-704, M30-714, M30-742, M30-801, M30-832, M30-841, M30-842, M30-852, M30-853, M30-861, M30-901, M30-941, M30-951, M30-993, M30-PM725B, M30-PM725G, M30-PM760B, M30-S309, M30-S3091, M30-S350, M30-S3501, M30-S730, M30-S7301, M30-S7301B, M30-S7302, M30-S7302B, M30-S7311, M30-S734B, M30-S734G, M30-S760, M35, M35-S320, M35-S3201, M35-S359, M35-S3591, M35-S3592, M35-S456, M35-S4561, M40-100, M40-101, M40-102, M40-103, M40-107, M40-114, M40-124, M40-129, M40-130, M40-133, M40-134, M40-135, M40-136, M40-140, M40-142, M40-145, M40-146, M40-148, M40-149, M40-150, M40-152, M40-154, M40-155, M40-183, M40-184, M40-185, M40-192, M40-193, M40-197, M40-221, M40-225, M40-230, M40-231, M40-232, M40-236, M40-237, M40-238, M40-239, M40-241, M40-243, M40-244, M30-245, M40-250, M40-276, M40-277, M40-284, M40-288, M40-289, M40-294, M40-295, M40-296, M40-300, M40-307, M40-313, M40-319, M40-S4111TD, M40-S4172TD, M40-S417TD, M45-S265, M45-S2651, M45-S2652, M45-S2653, M45-S269, M45-S2691, M45-S2692, M45-331, M45-S3311, M45-S351, M45-S3511, M45-S355, M45-S3551, M45-S3552, M45-S3553, M45-359, M45-3591, M45-SP459, M45-SP469, M5-S3112, M50-04N01N, M50-0TGO1D, M50-0TJO1E, M50-0YU01N, M50-130, M50-157, M30-159, M50-161, M50-S4182TD, M50-S418TD, M50-S181TD, M50-S5181TQ, M55-S135, M55-S1351, M55-S1352, M55-S2252, M55-S2253, M55-S325, M55-S3251, M55-S329, M55-S3291, M55-S3292, M55-S3293, M55-S3294, M55-S331, M55-S3311, M55-S3314, M55-S3315, M55-S351, M55-S3511, M55-S3512, M55-S3513, M55-S3514, M55-S3515, M55-S3516, M55-S3517, M55-S3518, M55-S3519, M55-S3520, M55-S3521, M55-S3522, M55-S3523, M55-S3524, M55-S3525, M55-S3526, M55-S3527, M55-S3528, M55-S3529, M55-S3530, M55-S3531, M55-S3532, M55-S3533, M55-S3534, M55-S3535, M55-S3536, M55-S3537, M55-S3538, M55-S3539, M55-S3540, M55-S3541, M55-S3542, M55-S3543, M55-S3544, M55-S3545, M55-S3546, M55-S3547, M55-S3548, M55-S3549, M55-S3550, M55-S3551, M55-S3552, M55-S3553, M55-S3554, M55-S3555, M55-S3556, M55-S3557, M55-S3558, M55-S3559, M55-S3560, M55-S3561, M55-S3562, M55-S3563, M55-S3564, M55-S3565, M55-S3566, M55-S3567, M55-S3568, M55-S3569, M55-S3570, M55-S3571, M55-S3572, M55-S3573, M55-S3574, M55-S3575, M55-S3576, M55-S3577, M55-S3578, M55-S3579, M55-S3580, M55-S3581, M55-S3582, M55-S3583, M55-S3584, M55-S3585, M55-S3586, M55-S3587, M55-S3588, M55-S3589, M55-S3590, M55-S3591, M55-S3592, M55-S3593, M55-S3594, M55-S3595, M55-S3596, M55-S3597, M55-S3598, M55-S3599, M55-S3600, M55-S3601, M55-S3602, M55-S3603, M55-S3604, M55-S3605, M55-S3606, M55-S3607, M55-S3608, M55-S3609, M55-S3610, M55-S3611, M55-S3612, M55-S3613, M55-S3614, M55-S3615, M55-S3616, M55-S3617, M55-S3618, M55-S3619, M55-S3620, M55-S3621, M55-S3622, R10-101, R10-S802TD, R10-S804TD, R10-S820, R10-S822, R10-S829, R10-ST2081, R10-ST4113, R10-S3503, R10-S3513, U200-148, U200-ST2091, U200-ST2092, U200-ST3311, U205, U205-S5002, U205-S5021, U205-S5022, U205-S5034, U205-S5044, U205-S5057, U205-S5058, U205-S5067, U205-S5068</p> <p>Satellite Pro: 2100, 2100-200Eb, 2100-200Ec, 2100-201Ec, 2100-203Eb, 2100-203Ec, 2100-220Eb, 2100-220Ec, 2100-221Eb, 2100-401Eb, 2100-402Eb, 2100-403Eb, 2100-403Ec, 2100-404Eb, 2100-404Ec, 2100-405Eb, 2100-405Ec, 2100-405EUe, 2100-406Eb, 4200, 4220, 4260DVD, 4280XDVD, 4280ZDVD, 430, 4300, 440CDT/CDX/CS, 445CDT/CDX, 4600, 4600CDT/CDX, 465CDT/XCDT, 4700CDT, 4800CDT, 4900CDT/CDT, 520CDT, 550CDT, 6000, 6050, 6070, 6100, A10, A100-828, A100-830, L10-110, L10-113, L10-222, L10-271, M10, M10-S405, M10-S406, M15, M15-S405, M15-S406, M30, M50, P100, P100-153, P100-327, P100-404, P100-465</p> <p>Tecra: 520CDT, 550CDT, 780CDM,</p>	205 (cont.)	<p>780DVD, 8000, 8100, 8200, 9000, 9100, A1, A2, A2-102, A2-105, A2-108, A2-113, A2-502, A2-512, A2-542, A2-552, A2-562, A2-572, A2-582, A2-703, A2-S119, A2-S139, A2-S202T, A2-S219, A2-S239, A2-S316, A2-S336, A2-S4372ST, A3, A3-S611, A3-S631, A3-S711, A3-S731, A4, A4-108, A4-109, A4-111, A4-123, A4-127, A4-128, A4-131, A4-132, A4-157, A4-158, A4-160, A4-161, A4-163, A4-164, A4-165, A4-166, A4-168, A4-170, A4-171, A4-177, A4-179, A4-181, A4-187, A4-196, A4-201, A4-203, A4-204, A4-205, A4-207, A4-210, A4-211, A4-212, A4-213, A4-221, A4-223, A4-227, A4-230, A4-232, A4-234, A4-244, A4-246, A4-249, A4-253, A4-255, A4-256, A4-257, A4-S111TD, A4-S211, A4-S216, A4-S236, A4-S236TD, A4-S313, A4-S313TD, A5, A5-101, A5-102, A5-104, A5-105, A5-109, A5-119, A5-120, A5-122, A5-132, A5-133, A5-134, A5-135, A5-138, A5-145, A5-148, A5-155, A5-159, A5-S116, A5-S237, A5-S416, A5-S516, A5-S6215TD, A5-SP519, A5-SP559, A6-104, A6-105, A6-171, A6-176, A6-EZ6311, A6-EZ6312, A6-EZ6411, A6-P3401, A6-S513, A6-S6312, A6-S713, A6-S713TD, A6-ST3512, A6-ST3512TD, A6-ST6315, A7-116, A7-117, A7-P5301, A7-S612, A7-S712, A7-ST5112, A7-ST7711, A7-ST7712, A8-EZ8311, A8-EZ8312, A8-EZ8313, A8-EZ8412, A8-EZ8413, A8-EZ8511, A8-EZ8512, A8-S8314, A8-S8414, A8-S8513, A8-S8514, M1, M2, M2-102, M2-107, M2-109, M2-171, M2-251, M2-302, M2-312, M2-402, M2-422, M2-D1500B, M2-D1600B, M2-D1600G, M2-D1800B, M2-D1800G, M2-P1700B, M2-P1700G, M2-S319, M2-S339, M2-S400, M2-S430, M2-S519, M2-S530, M2-S539, M2-S5392, M2-S630, M2-S730, M2-S7302ST, M2V, M2V-D1500G, M2V-P1600G, M2V-S300, M2V-S330, M2V-S3302ST, M3, M3 P-M730, M3 P-M740, M3 P-M750, M3 P-M760, M3-100, M3-101, M3-105, M3-112, M3-116, M3-117, M3-118, M3-122, M3-124, M3-127, M3-129, M3-131, M3-133, M3-134, M3-134, M3-137, M3-138, M3-142, M3-156, M3-166, M3-177, M3-183, M3-184, M3-185, M3-192, M3-221, M3-222, M3-226, M3-258, M3-264, M3-265, M3-272, M3-279, M3-281, M3-307, M3-326, M3-S212TD, M3-S311, M3-S316, M3-S316, M3-S331, M3-S336, M3-S636, M3-SP719, M4, M4-100, M4-101, M4-102, M4-103, M4-105, M4-107, M4-114, M4-133, M4-138, M4-146, M4-150, M4-151, M4-154, M4-158, M4-163, M4-S115TD, M4-S315, M4-S335, M4-S415, M4-S435, M4-S515, M4-S535, M4-SP625, M4-ST1112, M5-103, M5-104, M5-133, M5-S433, M5-S4331, M5-S4333, M5-S5331, M5-S5332, M5-ST1412, M5-ST5011, M5-ST5012, M6-EZ6611, M6-EZ6612, M6-ST3412, M6-S7311, M6-S7331, M6-ST4013, S1, S1-105, S1-115, S1-116, S1-118, S1-123, S1-141, S1-151, S1-202, S1-252, S1-272, S1-342, S1-362, S1-372, S1-382, S2, S2-S511TD, S2-S411TD, TE2000, TE2100, TE2300</p>



1211 North Miller Street
 Anaheim, CA 92806
 www.targus.com